

Better sleep makes better days!



WELCOME

Thank you for purchasing the Perfect Fit Adjustable Massage Bed. To learn how to use this product correctly, and to maximise your enjoyment and resulting health benefits, please read this Owner's Manual carefully. Please keep your Owner's Manual somewhere safe for future reference.



Safety Warnings

- Don't allow children to touch moveable parts of this product.
- The appliance is only to be used with the power supply unit provided.
- Please disconnect from power socket when not in use or before cleaning to avoid injury or damage to the product.
- Do not use accessories that are not recommended.
- · Do not use this product outdoors.
- Do not use for any other purpose except those listed in the manual.
- Maximum of 20 minutes of massage use is recommended.
- Do not use if any part of the device is damaged.
- Do not drop anything onto this product.
- Do not use the massage function if intoxicated or feeling unwell.
- Know your own body avoid using the massage function on a strength that may cause you injury.

Individuals who should not use this product

- Do not use the massage function if you are pregnant or have osteoporosis, heart disease or a pacemaker.
- Children under 14-years old should be supervised when using this machine.
- Do not use if advised not to by your doctor.
- Do not use if your body is wet e.g. following a bath or shower.
- Stop using if you feel unwell. If in serious discomfort consult your doctor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Safety

- · Do not leave in direct sunlight.
- Do not use near an open fire or heater.
- Do not spill water or drinks in this machine.
- Do not use a wet cloth to clean the electric components such as the switch and plug.
- Stop using product immediately if it malfunctions.

Do not use if you have a pre-existing medical condition; unless consulted and advised ok by a doctor.

The Importance of Sleep

The quality and quantity of the sleep you get has a direct effect on your ability to function during your waking hours. Sleep is a restorative process, during which time tissue and muscle repair takes place. Sleep is also thought to aid memory consolidation and learning, and help the brain process the information you've absorbed during the day. If you want to live longer, feel and look your best, and get the most out of every day, quality sleep is essential.

Your Perfect Fit Adjustable Massage Bed

Your Perfect Fit Adjustable Massage Bed combines the world's most comfortable bed with one of the most relaxing massages you'll ever have. So you'll enjoy a great night's sleep every night... and wake refreshed and rejuvenated every day.

Unique Multi-Layer Comfort System

A carefully crafted combination of spray-bonded cotton, polyester, gel memory foam, and a high-tech resilient foam gently cradles your body and supports your spinal column, hips, knees, joints, and shoulders. Plus the gel memory foam keeps you cool in summer... and warm in winter.

Vibrational Massage Therapy

At the press of a button, you can enjoy a relaxing therapeutic massage to support circulation, and gently massage those tired muscles, joints and sensitive pressure points. And you can increase massage intensity on both your upper and lower body to bring relief and rejuvenate your body from head-to-toe.

7 tips for better sleep

1. Make your bedroom a haven

Your bedroom should be your sanctuary at the end of a busy day. One way to ensure it is a restful sleeping space is to keep your bedroom focused only on sleep and intimacy.

2. Choose quality bedding

As a general rule, the higher the thread-count, the softer the sheet. They may cost a little more, but will pay dividends in greater comfort.

3. Install light dimmers

Softer lighting can help your body and mind wind down for the night... and it's more romantic.

4.Try a pleasant fragrance

A bedroom with a pleasant aroma is a room you'll enjoy being in. A subtle vanilla or lavender fragrance can help you relax.

5. Avoid electronic technology

Bright screens on smart phones, laptops, tablets and TVs emit blue light that our brains interpret as daylight, keeping us awake.

6. Avoid reminders of work

Reading paperwork, checking emails or reading text books in bed can keep the brain over-stimulated making it harder for us to switch off.

7. Keep your room dark and quiet

Once you're a sleep, a dark, quiet room can ensure you keep sleeping until you're ready to wake up naturally.



Assembly

Your Perfect Fit Adjustable Massage Bed features a humanized design, and requires minimal installation. All you need to do is install the bed legs following the steps below.

Screw all six legs into the underside of the bedframe **(Image A)**. Hand-tighten only. Do not over-tighten.



Install the power cord by connecting the cord jack to the connection on the control box (Image B). Ensure the power cord is connected completely and securely.



Overview

All of the functions of the bed can be operated with the remote control. The remote control comes with pre-programmed buttons that will be automatically adjusted when pressed, or you can manually control adjustments using the arrow buttons on the remote control. See (image C) for a complete list of remote control functions.





8



Remote Control Battery Installation

Remove the battery cover on the back of the remote control. Insert the AAA batteries (included).

Press the timer button and release

The 10 min LED light will flash once, indicating vibration time of 10 minutes.

Press the timer button twice for a 20 minute vibrating time, and three times for a 30 minute vibration time.

NOTE:

Preset buttons will move the head and foot of the bed simultaneously.

To immediately stop the movement of the bed during transition press any remote control button.



10

Custom Programming Preset Buttons

The three buttons shown in (image D) can be custom-programmed to positions of your choosing. To program the remote preset buttons:

1. Adjust the bed to the desired position.



The three buttons shown above are pre-programmed with the manufacture's suggested bed position. No programming is necessary by the purchaser unless modified bed positions are desired.

To Lock

Press and hold down both 'head + head down arrow' buttons simultaneously until the LEDs flash, the remote control will now be locked.





To Unlock


Press and hold down both 'foot + foot down arrow' buttons simultaneously until the LEDs flash, the remote control will now be unlocked.

You can enable automatic remote locking. This means the remote will automatically lock if it is not used for 5 minutes:









To turn on Auto Lock

Press and hold down both 'head + foot down arrow' buttons simultaneously until the LEDs flash, the remote control will now auto lock after 5 minutes of no use.





To turn off Auto Unlock

Press and hold down both 'foot + head down arrow' buttons simultaneously until the LEDs flash, the auto lock feature will now be disabled.


In the locked status the beds adjustable features will not be able to be moved. The massage feature can still be operated.





AUTO LOCK ON L





Remote Control Frequency Settings

There are several different frequency settings for independent control of multiple adjustable beds in the same area. To control two beds simultaneously, connect both control boxes with the control box connecting cable. With the connecting cable installed, both remote controls will operate the bed simultaneously even if the remote controls are on different frequency settings.

To Set a Frequency

- To adjusting the frequency Settings remove the battery cover from the remote control and adjust the DIP switch to the desired channel (see image E). Wait until the LED lights on the remote turn off (if LED lights are on).
- 2. Plug the bed power supply in to a power outlet.
- 3. Wait for a few seconds then press and hold the "Link Button" (see image G) on the bed base controller (located under the bed). The green "Link LED" (see image G) will turn on.
- 4. When the green "Link LED" turns off release the "Link Button", the green "Link LED" will flash.
- 5. Within fifteen seconds of the green "Link LED" flashing, press and hold the "HEAD UP" button and the "FOOT UP" button simultaneously until the LED lights on the remote control start flashing (see image F). When flashing release the two buttons.
- The LED lights will continue to flash until a successful sync with the control box is achieved. The frequency setting is now updated.
- 7. If the remote does not sync repeat the process and check the remote control Batteries.






Electric Component set up

Overview

The electronic components are pre-installed and no assembly is necessary. However, some setting and input locations are important for proper set up and functionality. (See images G & H) to become familiar with input, setting and part locations.





Overview

Important:

The backup battery is only to be used in case of a power outage.

Batteries are not to be used for normal operation of the bed.

Backup Battery Use

Use two (2) 9-volt alkaline batteries only (not included). If a power outage occurs install the 9-volt batteries into the provided battery pack on the power cord (image I). The backup battery will not support repeated movement for long periods of time. While using the backup battery it is recommended to move the head and foot of the bed independently rather than simultaneously. Do not use the "Flat" button to lower the bed. Do not use the massage motors when using the battery backup. If the remote control is missing the bed can be returned to the flat position by pressing and holding the emergency lower button located on the control box under the bed.

Remove the battery pack after power is restored as the system will continue to draw power from the battery, even if not in use.



Massage

Massage Function:

To activate the head massage function, press the "**HEAD**" button once, this will turn the head massage on at the soft intensity. Press the "**HEAD**" a second time to get the mid intensity massage, a third time for the high intensity head massage. To turn off head massage, press the "**HEAD**" button again.

To activate the foot massage function, press the "FOOT" button once, this will turn the head massage on at the soft intensity. Press the "FOOT" a second time to get the mid intensity massage, a third time for the high intensity head massage. To turn off head massage, press the "FOOT" button again.


To adjust the massage mode, press the massage mode button "6". The massage mode can be cycled through four vibration modes starting with long pulse, followed by medium pulse, then short pulse and finally continuous vibration.

Massage Timer:

Press the "**TIMER**" button to select a 10, 20, or 30 minute massage. Press a fourth time to turn the massage timer off. The blue light on the top of the remote control will flash once indicating which timer setting is activated.

The massage function will automatically turn off after 10 minutes if the timer is not set.

Allow the massaging system to rest for 30 minutes after automatic massage shut off.




Installing Side Stoppers

*ONLY FOR SPLIT-KING, LONG SINGLE & SPLIT-QUEEN

By installing the side stopers you will ensure that there is no sideways slippage of the mattress on the base of the bed.

Step 1Select the two shortest side stoppers and locate the side holes





Step 2

Insert one side stopper on each side of the bed base so that the horizontal bar is flush with the outside edge of the base.





Ensure the end stopper is also in place at the foot of the bed before placing the mattress onto the base.

Functions Test

Overview

To ensure proper setup, use remote and test all functions for 3 seconds. To control two beds simultaneously, connect both control boxes with the control box connecting cable . With the connecting cable installed, both remote controls will operate the bed even if the remote controls are on different frequency settings.

Important: Always return the base to the flat position when switching between preset options.

Trouble-Shooting

If one or more functions of the bed have stopped working:

Check under the bed base to verify the wired connections are secure and there are no cords or bedding obstructing the movement of the base.

The remote control lights no longer illuminate / the remote won't operate the bed functions:

Make sure the batteries are installed correctly or install three (3) new AAA batteries into the remote control. Ensure the frequency of the remote control is synced with the control box on the bed.

The remote control lights illuminate. However no functions of the bed will operate:

Check to ensure the power cords are properly connected. Unplug the base for 1 hour to reset the electronic components. Plug base into a different electrical outlet, or test current outlet with another working appliance. A grounded electrical surge protector is recommended with use of this product.

USB Charging Stations


Overview

Wake up to a fully charged device. These convenient USB charging ports will help reduce the clutter of plugs and cables around your bedroom, and ensure your device is where you need it, when you need it.

Specifications

2X USB Charging Stations (4X USB ports) USB Output Voltage: 5.1V±0.1V

USB Output Current: Max 2.1A







TEN (10) YEAR LIMITED REPLACEMENT WARRANTY STATEMENT

If your product becomes defective due to faulty material or workmanship within a period of 10 years from the date of purchase, we warrant to do the following:

- For New Zealand Consumers: We will replace the product with a new product, free of charge, or repair the product at our cost, at our discretion.
- For Australian Consumers: Our goods come with guarantees that cannot be
 excluded under the Australian Consumer Law. You are entitled to a replacement
 or refund for a major failure and for compensation for any other reasonably
 foreseeable loss or damage. You are also entitled to have the goods repaired or
 replaced if the goods fail to be of acceptable quality and the failure does not amount
 to a major failure.

Your warranty is subject to the following conditions:

- DO NOT operate the appliance with a damaged plug or cord, or if the unit has been
 dropped, damaged or dropped in water. To avoid the risk of electric shock, do not
 disassemble or attempt to repair the appliance on your own. If the supply cord is
 damaged, it must be replaced by a qualified electrician in order to avoid a
 hazard. Incorrect re-assembly or repair can cause a risk of electric shock or injury
 to persons when the appliance is used.
- The item has not been misused, abused, neglected, altered, modified or repaired by anyone.
- · The item has been subjected to fair wear and tear
- The item has not been used for trade, professional or hire purposes.
- The item has not sustained damage through foreign objects, substances or accident.

Your warranty does not cover;

- Components that are subject to natural wear and tear caused by normal use in accordance with operating instructions.
- Unauthorised/improper maintenance/handling or overload is excluded from this warranty.
- For guarantee claims, you will need to submit a proof of purchase in the form of a valid receipt that displays date and place of purchase.

This warranty does not replace but is in addition to your statutory rights.

This warranty does not apply to accessories supplied with the item.

This warranty applies only to the original purchaser and may not be transferred.

Replacement items will be covered by the limited warranty for the balance of the warranty period from the date of the original purchase.

Please note:

Only the defective product or parts returned to place of purchase will be replaced under this warranty.

Australia Contact

Brand Developers Aust Pty Ltd

Warehouse A, 9 Kimpton Way, Altona, VIC 3018, AUSTRALIA FAX: +61 3 9681 7825

AUST Customer Care: Email: customerservice@tvshop.com.au

Ph: 1800 890 840

New Zealand Contact

Brand Developers Limited

Unit H, 686 Rosebank Road,

Avondale 1026, Auckland, New Zealand Private Bag 93204, Parnell, Auckland 1151

FAX: +64 9 306 8203 **NZ Customer Care:**

Email: customerservice@tvshop.co.nz

Phone: 0800 002 999





Exclusively Distributed Throughout Australasia by:

Brand Developers Aust Pty Ltd

Warehouse A, 9 Kimpton Way, Altona, VIC 3018, AUSTRALIA AUST Customer Care: Email: customerservice@tvshop.com.au

Brand Developers Limited

Unit H, 686 Rosebank Road,
Avondale, 1026 Auckland, NEW ZEALAND
NZ Customer Care:
Email: customerservice@tvshop.co.nz

BDV2