

# REFLEX ACTIVE

## SPORT PLUS EARBUDS

# THANK YOU FOR CHOOSING REFLEX ACTIVE!

We know you want to get straight to the music, but please take a minute to read these instructions, they'll help you get the most from your Reflex Active product.

### SETTING UP

1. Remove earbuds from case once fully charged.
2. Open Bluetooth connections within phone or tablet settings.
3. Search 'Sport-Plus' and select. Your device will now be paired with your earbuds.  
Your connection will now be automatic, but if you do have any connection issues, please repeat steps 1-3. The earbuds will automatically shut down and charge when placed in the charging case.

### CHARGING THE CASE

1. Insert charging cable into the charging port at base of case & connect to power supply.
2. The charging indicator light will flash blue to show case is charging.
3. Allow to charge for around 1 hour, the charging indicator light will be illuminated continuously once fully charged.
4. Always take care not to over charge.
5. Earbud case shows RED when charging, soild BLUE when charged. Fully charged in 1 hour.

### CONTROLS

**PAUSE/PLAY** Tap twice on the left or right earbud.  
**NEXT TRACK** Triple tap the right earbud.  
**LAST TRACK** Triple tap the left earbud.  
**VOLUME UP** Tap four times on the right earbud.  
**VOLUME DOWN** Tap four times on the left earbud.  
**SIRI** Tap 5 times on the left or right earbud.  
**POWER OFF** Press and hold any earbud for 5 seconds.  
**POWER ON THE TWS** Press and hold for 5 seconds on each earbud and 'power on and pairing' will be heard.

### MAKING CALLS

**TAP TWICE** to answer incoming calls.  
**TAP TWICE** to hang up during calls.  
**PRESS AND HOLD FOR 2-3 SECONDS** to reject incoming calls.

### CARING FOR YOUR PRODUCT

Please follow these simple instructions to keep your Earbuds looking & sounding great!

• Clean product with a damp cloth & mild soap. • Not designed to be submerged in water, should this occur product will malfunction. • Keep away from steam & dust as these may affect quality of performance. • Avoid excessive twisting / turning of charging cable as this can cause malfunction. • Contains no serviceable components. Do not attempt to open the ear pods or their casing as this may cause harm. • Keep away from strong magnetic fields to avoid interference.

### GUARANTEE

Your Reflex Active product is guaranteed against any defective construction or parts for 1 year from date of purchase. Please retain your receipt as proof of purchase. Breakages caused by water damage, accident or mishandling are not covered. This guarantee is in addition to your statutory consumer rights.

In the unlikely event you need to return your Reflex Active product, please contact us and we'll be happy to guide you through the process.

### IMPORTANT INFORMATION

Enjoy your music, but please stay safe & ensure you stay aware of your surroundings at all times. We advise against listening to loud music for long periods of time. Do not use this product whilst driving or in other potentially dangerous situations. This product is not a toy, not for use by children. This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. Made in China by Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham International Business Park, B37 7GN. EU Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.

### DISPOSAL OF GOODS

The crossed out wheeltie bin symbol is to remind you that waste electrical products, batteries & accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility • Do not dispose of your product within household waste • Disposal of the packaging & your product should be done in accordance with local regulations • Batteries are not to be disposed of in municipal waste stream and require separate collection.

### EU DECLARATION OF CONFORMITY

The full UK & EU declaration of conformity can be viewed online at the following web page: <https://www.reflex-active.com/pages/audio-docc>

### HELP AND CONTACT

If you need any help with your product, then please get in touch, we'll be happy to hear from you! We are available Monday - Friday 9am - 4pm.

✉ [Support@Reflex-Active.Com](mailto:Support@Reflex-Active.Com) ☎ +44 (0) 121 524 1400

### SPECIFICATIONS

**BLUETOOTH VERSION / V5.0**  
**FREQUENCY / 20 Hz - 20kHz**  
**CHARGING CASE BATTERY CAPACITY / 230mAh**  
**EARBUD BATTERY CAPACITY / 30mAh\*2**  
**CALLING TIME / 5 HOURS**  
**CHARGING TIME / 1 HOUR**  
**STAND BY TIME / 250 HOURS**  
**WIRELESS RANGE / 15 - 20 METERS**



COME JOIN US OVER ON SOCIAL!

 REFLEX.ACTIVE

 REFLEX.ACTIVE