

#### GUARDIAN SL™ BUG NET SET UP


BEFORE SETTING UP YOUR GUARDIAN SL. CAREFULLY FOLLOW THE SET UP INSTRUCTIONS PROVIDED WITH YOUR ENO HAMMOCK AND SUSPENSION SYSTEM.



both open ends of the Guardian SI



Connect the webbing loop at the narrow end to your hammock's carabiner, and tension closed.



Connect the webbing loop at the end of the integrated ridgeline to the other carabiner. Tension the ridgeline by pulling the cord through the LineLoc tensioner until the ridgeline is level.



Slide the Guardian SL down the ridgeline to relax in your hammock before the bugs come out.



To protect yourself from bugs, pull the Guardian SL back over your hammock and tension the wide end closed, and relax!



To integrate with ENO Sub series hammocks, loop webbing loops around hammock toggles after connecting to suspension system.

#### Eagles Nest Outfitters, Inc. 601 Sweeten Creek Industrial Park Asheville, NC 28803 ph: 828.252.7808

mail@enonation.com



EXCLUSIVE OF TRI

# **ACCIDENTS HAPPEN**

- · Never hang your hammock higher than 18-inches off the ground.
- Always make sure to check the area beneath the hammock is free of sharp objects, rocks, trash, and any other debris that could create a hazard in the case of a fall.
- Before every use, fully inspect your hammock including carabiners and rope and your suspension system to check for snags, fraying, and general wear and tear in addition to anything unusual and/or different from the time of purchase. If anything suspect is found during inspection, please discontinue use.
- · Do not permit children to use unattended.
- · Do not jump or swing aggressively in hammock.
- Always follow provided instructions.
- · Always test the hammock before putting your full weight into it.
- · Do not stack hammocks vertically.
- Do not modify, after market modifications will void your warranty.
- Do not until hammock knots (found at the ends of the hammock).

FOR MORE INFORMATION VISIT ENONATION.COM/SAFETY

# PRODUCT CARE

With proper care, your Guardian SL will provide countless hours of relaxation.

- Keep it out of direct UV light when not in use and store dry in a cool place.
- Never leave your hammock unattended.
- Prevent damage by removing sharp items in pockets and debris from shoes.
  Hammocks are flammable; keep away from open flames and embers.
- Get it dirty? Hand wash in cold water using a mild detergent. Hang dry and you're back in the game!

FOR MORE INFORMATION VISIT ENONATION, COM/CARE

### WARRANTY

ENO warrants our product to be in good condition upon receipt and free from manufacturing defects for a period of 2-years from the original date of purchase.

This warranty only covers manufacturing defects and does not cover:

- UV Damage (discoloration and brittleness causes tearing)
- Elemental/Accidental Damage (wind, burns, animal bites)
- · Improper care or use (hanging over 18", jumping, swinging)
- Normal wear and tear
- After-market design modifications

FOR MORE INFORMATION VISIT ENONATION.COM/WARRANTY

It truly means the world to us that you have chosen to make ENO part of your life. Welcome to the family! The highest compliment we could possibly receive is for you to tell your friends about us. If you enjoy these ENO products as much as we do, then please consider spreading the hammock word.

Keep exploring, adventuring and relaxing...we hope to see you around! Yours in hammocks.

