
LOUNGER SL™ CHAIR SET UP

THE LOUNGER SL CHAIR MUST BE SET UP ON A STABLE, LEVEL SURFACE. USE ONLY UNDER SAFE CONDITIONS. KEEP CHAIR OUT OF UV LIGHT WHEN NOT IN USE. DO NOT LEAVE OUTSIDE PERMANENTLY.



all chair hub sockets, saving the joint with an arrow for last.



Install chair seat on assembled frame by fully pushing the corner pockets onto the aluminum pole ends.



To re-pack chair, remove poles from hub sockets, fold chair seat in half and roll up chair in seat.

Eagles Nest Outfitters, Inc. 601 Sweeten Creek Industrial Park

601 Sweeten Creek Industrial Parl Asheville, NC 28803 ph: 828.252.7808 mail@enonation.com



ACCIDENTS HAPPEN

- · Always follow provided instructions. Use only under safe conditions.
- . This lightweight chair is rated to a maximum of 250 lbs.
- Always test the chair to ensure it is assembled correctly before putting your full weight into it.
- · Do not jump, bounce or swing aggressively in the chair.
- Always make sure to check the area beneath the chair is free of sharp objects, rocks, trash, and any other debris that could create a hazard.
- Before every use, fully inspect including chair seat, aluminum frame and plastic hubs for snags, fraying, cracks and general wear and tear in addition to anything unusual and/or different from the time of purchase. If anything suspect is found during inspection, please discontinue use,
- · Do not permit children to use unattended
- · Do not drop or strike chair on ground or other objects,
- Do not modify, after market modifications will void your warranty.
 FOR MORE INFORMATION VISIT ENONATION.COM/SAFETY

PRODUCT CARE

With proper care, your chair will provide countless hours of relaxation.

- Keep it out of direct UV light when not in use and store dry in a cool place.
- · Never leave your chair unattended.
- · Prevent damage by removing sharp items in pockets.
- Chairs are flammable; keep away from open flames and embers.
- Get it dirty? Hand wash in cold water using a mild detergent. Allow to fully dry before storage.

FOR MORE INFORMATION VISIT ENONATION, COM/CARE

WARRANTY

ENO warrants our product to be in good condition upon receipt and free from manufacturing defects for a period of 2-years from the original date of purchase,

This warranty only covers manufacturing defects and does not cover:

- UV Damage (discoloration and brittleness causes tearing)
- Elemental/Accidental Damage (wind, burns, animal bites)
- · Improper care or use (hanging over 24", jumping, swinging)
- · Normal wear and tear
- After-market design modifications

FOR MORE INFORMATION VISIT ENONATION.COM/WARRANTY

It truly means the world to us that you have chosen to make ENO part of your life. Welcome to the family! The highest compliment we could possibly receive is for you to tell your friends about us. If you enjoy these ENO products as much as we do, then please consider spreading the hammock word.

Keep exploring, adventuring and relaxing...we hope to see you around! Yours in hammocks.

