



USER'S GUIDE

Manufactured by Blisslights Phone: (626) 709-3319 Fax: (626) 205-4013 www.BlissLights.com support@BlissLights.com MADE IN USA



Please ONLY use manufacture provided transformer

Contents

Notice	1
Before you begin	2
Parts List	2
Setting up the BlissLights Spright	3
Operating the BlissLights Spright	4
Installation Tips	4
Product Specifications	5
Limited Warranty	6

Notice

CAUTION – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

This laser product is certified as a CLASS 2M laser product to the requirements of the US Federal Laser Product Performance Standard (FLPPS) contained in the regulations in 21 CFR Subchapter J. Class 2 laser products can be hazardous when directly viewed.

Avoid direct viewing of Class 2M laser energy. For reference the FLPPS requirements for demonstration laser products like laser pointers are limited to Class 2M levels of laser energy. This product uses diffractive optics to scatter the beam energy. This scattering effect causes the energy concentration to drop below the exposure limits for momentary or accidental viewing at a relatively short distance from the laser aperture. As similar with all bright light sources, when you operate this device in unsupervised general public areas, it is recommended that up close access to the Blisslights be restricted or prevented.

This laser display device incorporates a Class 2M laser system which, by itself, may be hazardous. However, this laser display device incorporates a protective housing and diffractive holographic optics in the machine design such that there is no exposure or human access to laser radiation during operation or maintenance above the Class 2 limits. Each individual laser beam power is under 1mw which is less than a standard laser pointer.

UNDER NO CIRCUMSTANCE shall attempts be made to open the protective housing or operate the device if the aperture windows are damaged.

All service to this laser display device requiring the protective housing to be opened and/ or removed shall be performed by Blisslights service personnel or their authorized agents. Opening the BlissLights protective housing voids the warranty.


NO LASERS SHOULD BE POINTED INTO THE SKY WITH 10 NAUTICAL MILES OF AN AIRPORT. IF YOU ARE LOCATED WITHIN THIS SPECIFIC PERIMETER WE RECOMMEND THE LASERS BE POINTED DOWN AT THE GROUND SO NO STRAY BEAMS ARE PROJECTED INTO THE AIR.

Thank you for purchasing the BlissLights Spright. The BlissLights Spright projects thousands of green pin points of light that is perfect for putting "fireflies" in your garden or creating a truly unique holiday display. We hope you enjoy this incredibly unique lighting fixture.

Before you Begin

Immediately upon receiving a fixture, carefully unpack the carton, check the contents to ensure that all parts are present, and have been received in good condition. Notify the shipper immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a fixture must be returned to the factory, it is important that the fixture be returned in the original factory box. Please see parts list below for box contents.

Parts List





(1) Transformer



Setting up the BlissLights

Before operating the BlissLights Spright, please read the "Before you Begin" section and "Notice" section of this user guide.

STEP 1: First locate the 2-prong plug connected to the cable exiting the BlissLights Spright head. Plug this end into the matching hole on the end of the 12V Manufacture provided transformer. Screw the cap on to complete the water tight seal. Next plug the standard 3-prong plug on the other end of the transformer into an outdoor/Indoor outlet.



STEP 2: Stake the BlissLights Spright into the desired location. To attach or detach the stake, twist the stake into place on the bottom of the Spright. Do not use fixture head to stake light into the ground, grasp by stake only. Use the thumb screw on the side of the fixture to adjust the angle.




Operating the BlissLights Spright

The BlissLights Spright operates in temperatures of -150 F to 900 F. There may be a slight delay if operating in temperatures below 55 o F. Please allow up to 10 minutes for light to warm up and reach its full projection.

Installation Tips

- For scheduled or nighttime-only operation, use with a timer. **Do** not connect the light to a dimmer pack, it will damage the light. Use with manufacture provided transformer only.
- The darker the area the light is being used in, the brighter the projection. Try to stay away from areas with street lights or other bright lights.
- If you are going to hang the BlissLights Spright, it is recommended that, for safety purposes, your lights are properly mounted using a suitable hanging clip and safety cable.
- The BlissLights Spright will cover an area of about 30' X 30' for every 10 feet away from surface (equivalent to the size of about 2 two-car garages).



Product Specifications

	BlissLights Spright		
Laser Classification	Class 2M		
Maximum Laser Power (Single Beam)	Less than 1 mw		
Laser Wavelength	532 nm – Green 650nm-Red, 445nm-Blue		
Laser Optics	Single source holographic optical element		
Power Consumption	Up to 8 watts		
Power Input	110/120V (when used with manufacturer provided transforme		
Operation	Indoor / Outdoor		
Operating Temperature	-15° F to 90° F		
Projection Coverage	30ft. X 30ft.		
Maintenance	Maintenance Free		
Dimensions	13"H x 5 "L x 4"W		
Warranty	Limited 1 Year		

For tips and ideas visit www.blisslights.com where you can also learn more about other Blisslights products and accessories.





LIMITED WARRANTY

The manufacturer warrants this product to be free from defects in materials and workmanship for a period of one (1) year from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss of damage, including any labor/expense costs involved in the replacement or repair of said product. Please contact BlissLiahts at support@blisslichts.com. or (626) 709-3319.

Owner Registration Card

Please fill out, cut along dashed line, affix proper postage and return this Owner registration card within 10 days to insure that your new BlissLightsis covered by the limited warranty. You can also go to **www.blisslights.com** and fill out your registration card online.

Mailing Address: BlissLights, 1155 Industrial Avenue, Escondido, CA 92029

Purchaser's Name	
Address	
State	Zip
Email:	
BlissLights Product:	
Where Purchased (Store Name) _	
Where will the BlissLight be used: .	
If commercial institution, what typ	oe of business?
RestaurantBarStoreOffic	ce _Other
If home installation, where?	
WalkwayPatioGarden Are	eaPorchOther
Model/UPC Number:	