



How to Use the Lodge Kickoff Grill Portable Cast Iron Grill (L12RG)

Kickoff Grill™ - just like all of our cast iron cookware, we've seasoned the Kickoff Grill right in our foundry, making it ready to use and easy to care for. Follow these easy steps to get started grilling:

1. Place the cast iron grill on the ground, concrete, an outdoor cooking table, or cinder blocks.
2. Use a chimney starter to light your charcoal, then place the lit coals in the base of the Kickoff Grill.
3. Use the included Hook & Carry Handles to set the domed grill grate on top of the base. You can rotate the grill grate to adjust the airflow to dial in the temperature.
4. Remove the grill grate with the Hook & Carry Handles to add more coals as needed.
5. Apply oil to the grill to avoid food sticking.
6. Cook your food and enjoy.