


### FLO X SPLIT CLAMP


FLX/018/AS01




### CONFIGURE CLAMP BRACKET

If required change the clamp plate setting by removing the screws and adjusting to correct setting

### Desk Thickness Range




INSTALL CLAMP SCREW AND CLAMP



FIT CLAMP TO DESK


FOLD




## TIGHTEN CLAMP SCREW




# CONFIGURE 180° STOP (if required)






# FIT CLAMP COVER AND BUSH



# ALTERNATIVE INSTALLATION METHODS FOR RESTRICTED GAP AT REAR OF WORK SURFACE



### A WARNING

- Do not use this product for any purpose other than that for which it was designed
- Ensure desk/worksurface is suitable to take the weight of the arm/s and monitors
- Supported weight must not exceed the maxium load per arm
- Take care when installing as fingers could become trapped

### A MAINTENANCE AND INSPECTION

- Ensure all screws are tightened and occasionally adjust if needed
- Ensure arm is pushed fully down onto the clamp before installing the monitor(s)
- Clean with a damp cloth, NO solvents

## A DISCLAIMERS

- The use of power tools, lever bars or excessive force during the installation, or re-configuration of the product will invalidate your guarantee
- Failure to observe the recommendations in the use, and configuration of these products may affect your guarantee
- As a part of Colebrook Bosson Saunders ongoing product improvement programme the design of products may change without prior notice and details may vary from those illustrated

## PATENTS

Colebrook Bosson Saunders hold a number of patents and other intellectual property rights covering our products and processes. You can find patent information on our website at:

www.colebrookbossonsaunders.com/patents

Please consider leaving these instructions with the product if further installation may be required by others

FLX-018-AS01-INST-A-SEPT-2022



| FOLD FOLD Print size - A4 297mm x 210mm