


# Quick Usage

## Interface Introduction

### Home Interface



No.	Description
1	Control access to different pages: Home/Phone/Contacts/Settings. - Home: The current page where you can start a meeting. - Phone: Make a phone call. - Contacts: Call a contact. - Settings: Configure device settings.
2	The local time.
3	Start a scheduled meeting.
4	Start an instant meeting.
5	Join a Zoom meeting by entering a meeting ID.
6	Share content from your laptop or mobile device.

7	Control the device using voice commands.
---	--


Meeting Interface



No.	Description
1	Meeting Information.
2	Meeting Controls.

Yealink RoomConnect Software Interface

You need to switch the system to Zoom Rooms mode (For more information, please refer to [Switch Account](#). Open the Yealink RoomConnect application, and the software interface is as follows.



No.	Description
1	Display basic device information, and click to enter the device details setting.
2	Basic software information and device management server configuration.

## 2. General Feature

When the administrator completes the [Quick Setup](#), the device can start working usually.

Description	Related Document
Start an instant meeting	<a href="#">Instant Meeting</a>
Join the meeting	<a href="#">Join Meeting</a>
Starting sharing via a cable	<a href="#">Share Content via Cable</a>
Starting sharing via the WPP20	<a href="#">Share Content via WPP20</a>
Camera control	<a href="#">Basic Settings</a>