## Assembly Instruction 194S9336DG-3 SOFA

Legs & hardware are stored in the bottom of the seat,please take out for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.

## **Component list**

NO.	Drawing	Description	QTY(pc)
A	<u> </u>	Washer 1-3/10"	1
В	L C	Middle Plastic Leg 7-4/5*2-3/4"	1
С		Wooden Leg 7*1-1/2"	4
D		Seat	1

Page 1 of 2

