


ASSEMBLY INSTRUCTION INSTRUCTIONS D'ASSEMBLAGE

Item No : 196H4522-17 / 196H4522WH-17
Description : CORNER



I M P O R T A N T N O T E :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws / bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

PART LIST LISTE DE PIECES		
NO	DESCRIPTION	QTY/PCS
1	CORNER TOP	1 PC
2	LEG	4 PCS
3	STRETCHER	4 PCS

HARDWARE LIST LISTE DE QUINCAILLERIE		
NO	DESCRIPTION	QTY/PCS
A	JCBC BOLT / BOULON M6 x 1.0 x 70mm	8 PCS
B	SPRING WASHER / RONDELLE D' ARRET 1/4" x 9/32" x 15/32" x 0.04"	8 PCS
C	FLAT WASHER / RONDELLE PLATE 1/4" x 9/32" x 3/4" x 0.04"	8 PCS
D	ALLEN KEY / CLE ALLEN M4 x 60mm	1 PC
E	CSK SCREW / VIS M4 x 45mm	8 PCS

