Operation Manual

SPYCRUSHERS 8GB USB FLASH DRIVE VOICE RECORDER



www.spycrushers.com

Operation Manual

BEFORE YOU BEGIN...

IMPORTANT NOTE: Please fully charge your device before use (5-8hrs).

IMPORTANT NOTE: Prohibition against eavesdropping

All jurisdictions have specific laws and regulations relating to the use of cameras and video recorders. Before using any camera or video recorder for any purpose, it is the buyer's responsibility to be aware of all applicable laws and regulations that prohibit or limit the use of such products and to comply with the applicable laws and regulations.

Product Layout:



Status light: the red light is power indicator light.

Start Recording: Move the On/Off Rec-Switch button to the side marked "REC"; after 2 seconds a blue light will flash then a red light. Once the red light goes out the device is recording.

Stop Recording: Move the Rec-switch to the side marked "STOP".

Play: Connect to computer, copy recording files to the computer, and play recording via the computer's Media Player.



Operation Manual

Charging: Connect device to your computer. The red light will flash repeatedly and start charging up automatically. When the battery is fully charged the red light will stop flashing and go solid.

USB Flash Drive: To use as a USB Flash Drive move the On/Off Recswitch button to "STOP" and proceed as normal.

Connected Recording: While recording if the battery is being exhausted the device can be connected to a computer or power source for continued recording while charging.

Important:

Low Power- When the battery is low the red-power-light will flash repeatedly. Please stop recording and save the recorded file.

Automatic Save- While recording if the battery is being exhausted, the device will stop and saves recorded files automatically.

Reset- If device is not performing insert a non-metallic object into the reset hole and press the reset button. The device will then function as normal.

Non-Recording- If memory is full the device will not record. Please transfer recorded files to replenish storage space.

Charge- When using a charger, please use good quality charger. When charging up, do not place device on the bed, pillows or where children are likely to touch.

Waterproof- This device is not waterproof, please keep dry.

Interference- All devices may be subject to magnetic interference, please stay far away from sources of magnetic interference.

Safety- This device may contain small parts. Keep out of reach of small children.

File backup- To avoid operational errors that may result in lost files, please backup your files.

File transfer- Do no disconnect device from your computer when transferring files. Make sure all desired files are completely transferred before safely disconnecting your device.



Operation Manual

Specifications:

Specifications	
Size	70*21*9.4mm
Weight	14g
Recording Format	(WAV)
Sample	48KHZ/ 192Kbps
Recording Time	Memory 8G: 150 hours
Computer System	Windows vista/xp/2000/7
Power Supply	Recording: 15 hours
Power	Lithium Battery, charge up: input DV5.0V

WARRANTY INFORMATION:

SpyCrushers brand and all SpyCrushers products are owned and operated by Crushers, Inc. Crushers, Inc warrants this product against defects in workmanship and material for a period of one (1) year from its original purchase date. You must present your receipt as proof of date of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labor or replaced at the sole discretion of Crushers, Inc.. The end user is responsible for all freight charges incurred to send the product to Crushers Inc's repair centers. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of purchase. The warranty does not cover any incidental, accidental or consequential damages arising from the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user

Operation Manual

or third party modifications to any component or evidence of misuse or abuse of the device will render all warranties void.

By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.

Crushers Inc.

info@crushersinc.net

© Crushers Corporation Communications 2013

FCC VERIFICATION:

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help WARNING: Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

Connect, friend and follow SpyCrushers for product specials, discounts and more.

http://www.spycrushers.com http://www.facebook.com/spycrushers http://www.twitter.com/spycrushers http://www.youtube.com/user/spycrushers

Click Here For Free & Deeply Discounted Crushers, Inc. Products. Join Our VIPGroup Today. It's Free!

http://www.vipgroup.crushersinc.net

