

# IN6-W Instructions Turf-Tec Driving Plate For Turf-Tec 6 and 12 inch Infiltration Rings

(IN5-W, IN7-W and IN8-W models)



The new driving plate for the Turf-Tec 6 and 12 inch Infiltration Rings allow the infiltration rings to be hammered into the ground for ease of insertion. The specially designed plate fits directly overtop the center handle assembly on the IN5-W, IN7-W and IN8-W model Infiltration Rings.

The driving plates are made of 1/4 inch thick steel and are welded together to provide strength. The driving plates can be used with a hammer or with the jacking method allowing an even distribution of weight for proper soil insertion.



### **Specifications:**

- 1/4th inch thick steel
- Designed to fit over center handle for all three models of Turf-Tec 6 and 12 inch Infiltration Rings
- Size 14 inch X 14 Inch
- Weight 15 pounds
- Easy to use



### **IN6-W** Turf-Tec 6 and 12 inch Infiltration Ring Driving Plate

Copyright 2020 - Patent pending



## Use a heavy jack under the back end of a truck to drive rings as an alternative to the sledge method.

- 1. Position the Turf-Tec IN6-W driving plates over the IN5, IN7 or IN8 6 and 12 inch Infiltration rings so the center bar is in the center of the two plates as shown.
- 2. For lessen vibration and to reduce wear on the infiltration rings, a ¼ inch (0.25") rubber or neoprene gasket (not provided) can be placed between the driving plate and the infiltration rings.



- 3. Center a suitable wood block across the Turf-Tec IN6-W Steel Driving Plates.
- 4. Center a jack on the driving plate or wood blocks. Place the top of the jack and the assembled items vertically under the previously positioned end of a truck body and apply force to the ring by means of the jack and truck reaction.
- 5. Also, tamp near the edges or near the center of the ring with the rubber mallet, as slight tamping and vibrations will reduce hang-ups and tilting of the ring.
- 6. Check the rings with the level, correcting the attitude of the rings to be vertical, as needed.
- 7. Remove driving plate and begin testing.

### LIMITED WARRANTY OF TURF-TEC INTERNATIONAL PRODUCTS

Turfgrass Products Corporation - dba - Turf-Tec International ("Seller") warrants to the final purchaser, that all Turf-Tec International tools will be free from defects in material or workmanship for a period of one year from date of purchase. SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the repair or replacement of parts, without charge, which are defective in material or workmanship and which have not been misused, carelessly handled, or improperly repaired by persons other than Turf-Tec International. To make a claim under this Limited Warranty, you must return the complete tool, transportation prepaid, to Turf-Tec International after contacting Turf-Tec International and receiving a return authorization number. Please include a dated proof of purchase with your tool.

ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO ONE YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT.

#### Hold Harmless Agreement

The seller shall protect, defend, indemnify and hold the purchaser and their respective assigns and their attorneys, accountants, employees, officers and directors harmless from and against all losses, costs, liabilities, claims, damages and expenses of every kind and character, as incurred, resulting from or relating to or arising out of the inaccuracy of results, injury of user, injury of sports participant, turfgrass loss, warranty, covenant or any agreement made by the seller in this agreement.