
### Seek & Ramble

HARRISON SIDE TABLE ASH




ASSEMBLY GUIDE



### Seek & Ramble

### CONTENTS

#### PART LIST



WE WANT TO BE KINDER TO THE ENVIRONMENT. THAT IS WHY WE HAVE CHOSEN TO USE LITTLE TO NO PLASTIC.

PLEASE REUSE OR RECYCLE ALL CARDBOARD PACKAGING.



## Seek & Ramble ASSEMBLY STEPS

ENSURE YOU PLACE A RUG OR PROTECTIVE SURFACE DOWN TO COMPLETE ASSEMBLY. PROTECT THE FLOOR AND THE PRODUCT FINISHES.

STEP 1

LAY OUT ALL PARTS. LEAVE THE TOP WRAPPED AND PUT IT SAFELY ASIDE. IT WILL BE THE LAST PIECE USED.

STEP 2

PLACE THE BASE (PART 1) SECURELY ON THE FLOOR

STEP 3

SCREW THE CONNECTOR (PART 2) INTO THE BASE (PART 1)

NOTE - ENSURE TO LINE UP THE CONNECTOR THREAD TO THE BASE BEFORE TIGHTENING TO AVOID THREADING THE CONNECTOR

STEP 4

CAREFULLY UNWRAP THE TOP (PART 3) AND PLACE IT FACE DOWN ON THE FLOOR (USE A BLANKET OR MAT TO PROTECT THE FLOOR AND THE TABLETOP)


LINE UP THE THREAD HOLES TO THE CONNECTOR HEAD (PART 2) AND TIGHTEN THE SCREWS (PART 4)

STEP 5

PLACE THE TABLE INTO POSITION AND STYLE IT WITH YOUR FAVOURITE TREASURES OR DÉCOR PIECES.



# Seek & Ramble ASSEMBLY STEPS




STAND THE BASE (PART 1) ON A STABLE FLOOR.

SCREW THE CONNECTOR (PART 2) INTO THE BASE (PART 1)

NOTE: CAREFULLY ALIGN THE THREAD TO THE BASE BEFORE TIGHTENING



# Seek & Ramble ASSEMBLY STEPS



CAREFULLY UNWRAP THE TOP (PART 3) AND PLACE IT FACE DOWN ON THE FLOOR (USE A BLANKET OR MAT TO PROTECT THE FLOOR AND THE TABLETOP)

LINE UP THE THREAD HOLES TO THE CONNECTOR HEAD (PART 2) AND TIGHTEN THE SCREWS (PART 4)

NOTE: DO NOT FULLY TIGHTEN SCREWS UNTIL ALL SCREWS ARE IN POSITION.



# Seek & Ramble CARE TIPS

Note – use non-abrasive furniture cleaners to ensure your table receives the best care.

- Always read the label of cleaning products to ensure suitability before using.
- Spills should be soaked up immediately with a clean, absorbent soft cloth or paper towel.
- Avoid putting acidic material, such as lemon juice, onto your tabletop.
- Keep product out of direct sunlight. The timber veneer or wood will lighten and surface finishes may degrade if exposed to bright sunlight.
- Wipe timber veneer or wood with a damp cloth. Avoid THE use of household chemicals and cleaners.
  - Spills must be soaked up immediately with a clean absorbent cloth or paper towel.
  - We recommend the use of coasters and placemats to prevent damage.

Tip - Check the top and base regularly and retighten if necessary.



SCAN FOR MORE PRODUCT INFO

