

29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au

# Installation Manual

## CHAM-TOUCH-3C

Date: May 19, 2022 12:19 PM

Variant	Item No.	Detail
20144	CHAM-TOUCH-3C	3CH Wall Controller

Thank you for purchasing your new CHAM-TOUCH-3C Wall Controller, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

# Specifications


Type of controller:	RGBW touch wall control	Cutout (mm):	(L) 70 <sub>mm ×</sub> (W) 44 <sub>mm ×</sub> (D) 20 <sub>mm</sub>
Output signal:	RF + Bluetooth	Transmission frequency:	2.4GHz
Dimming range:	0.1% - 100%	Operating temperature:	0-40°C
Colour:	White (Glass)	Power consumption:	< 15mA
Dimensions (mm):	(L) 120mm x (W) 75mm x (D) 29.1mm	Operation voltage:	240V

- Touch sensitive
- Glass interface(white & black)
- Compatible with all universal series RF+Bluetooth receivers
- Radio frequency: 2.4GHz
- Control RGBW colour
- Control 1 zone/area
- Waterproof grade: IP20

#### Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

#### Function Introduction



Note:

-The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use

-Keep away from hot steam and corrosive gas




29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433


enquiries@domuslighting.com.au | www.domuslighting.com.au


Installation Manual

## Function Introduction



# Wiring Diagram





Note:

-The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use

-Keep away from hot steam and corrosive gas



29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

#### **Operation**

- 1. Do wiring the wall panel & RF+Bluetooth receiver according to wiring diagram (please refer to the instruction of RF+Bluetooth receiver that you would like to pair with).
- 2. Power on, then touch the button  $\circlearrowleft$  to turn on the controller, indicator of the controller turned blue.

#### Pair with RF+Bluetooth receiver





Step 1: Click the "Prog. Key" on RF+Bluetooth receiver (or reset power of the receiver 3 times continuously if the button is not accessible) to set it into pairing to RF+Bluetooth remote status.

Step 2: Touch the colour wheel, LED lights connected with the RF+Bluetooth receiver flicker once means the receiver is paired with the wall panel successfully.

### Built-in 10 colour changing modes are as follows:

Mode 1:	Any two colours of RGB mix fade-in & fade-out			
Mode 2:	RGB three colours mix fade-in & fade-out			
Mode 3:	RGB three colours mix fade-out & fade-in			
Mode 4:	RGB flash			
Mode 5:	RGB three colours fade-in & fade-out successively			
Mode 6:	RGB three colours fade-in successively			
Mode 7:	RGB three colours fade-out successively			
Mode 8:	RGB three colours jump changing successively			
Mode 9:	R&B two colours mix fade (R in B out), then G fade-in, then R&B mix fade (R out B in), then G fade-out			
Mode 10:	B fade-out, then G&B mix fade (G out B in), then R&G mix fade (R out G in), then R fade-in			

-The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Keep away from hot steam and corrosive gas