

# BAMBURY

## **IMPORTANT INSTRUCTIONS - RETAIN FOR FUTURE USE**

Please ensure the contents of this manual are read carefully before operating your new appliance, even if you are familiar with this type of product

## SAFETY PRECAUTIONS

## DO

**DO** use as an under blanket only

**DO** switch off at the power outlet and remove the plug when the electric blanket is not in use

**DO** ensure that the electric blanket is used only on an alternating current supply circuit of the proper voltage

**DO** allow the electric blanket to cool down before folding and storing

**DO** frequently examine for signs of wear on the blanket, controller and cord

**DO** discontinue use immediately if any abnormality or defect appears during operation, and consult the place of purchase or the supplier regarding its repair

**DO** have the electric blanket inspected by a qualified and registered person after 3 years of use. Repairs, by law, must be undertaken by a qualified and registered electrician

**DO** carefully follow the instructions for machine, hand washing and localised soiling (Tie Down model excluded)

**DO** detach the controller before washing the electric blanket (Tie Down model excluded)

**DO** keep the supplied flexible cord and switch outside of the bed, as far away as practical

**DO** keep the control unit away from open windows

**DO** ensure that the heating area (element) on any side of the bed does not hang over the edge of the mattress, and that the size of the electric blanket is suitable for the intended mattress

**DO** keep the electric blanket in the fully spread position at all times during use to avoid overheating. It is imperative that the electric blanket is frequently inspected to ensure that this condition is maintained

**DO** ensure that children are supervised while using the device that they do not play with the appliance

### DO NOT

**DO NOT** use the electric blanket for anything other than domestic use only. It is not intended for use in hospitals

**DO NOT** use this electric blanket on an adjustable bed, futon or similar, in which the cord can be caught, tangled, rucked or damaged

**DO NOT** use the electric blanket on a water bed

**DO NOT** allow young children or infirm persons to use the electric blanket without supervision unless the controls have been pre-set by a parent or guardian, or unless the child has been adequately instructed on how to operate the controls safely

**DO NOT** allow persons (including children) with reduced physical, sensory or mental capabilities, or lack of exprience and knowledge, to use the appliance unless they have been given supervision or adequate instructions by a person responsible for thier safety

**DO NOT** allow children under the age of three or infirm persons to use this appliance due to their inability to react to overheating

**DO NOT** allow persons suffering from bed-wetting to use this electric blanket

**DO NOT** use for pets, this is for human use only

**DO NOT** switch the power on if the electric blanket is wet or folded

**DO NOT** use the electric blanket at the high settings for an extended period of time, as it can result in skin burns

**DO NOT** use when tucked in or folded

**DO NOT** use pins on, or through the electric blanket as this can cause damage to the electrical wiring

**DO NOT** leave heavy objects on the bed when the unit is switched on, e.g. folded blankets, clothes, suitcases, etc.

**DO NOT** dry clean the electric blanket. Dry cleaning liquid may have a harmful effect on the insulation or covering of the heating unit

**DO NOT** fold too tightly when storing. Fold neatly without sharp bends in the heatling element and store where no objects will be placed on top of it. Avoid pressing creases into the electric blanket

**DO NOT** use if the supply cord is damaged. It must be replaced by the manurfacturer, its service agent or similarly qualified persons in order to avoid a hazard

## **SAFETY PRECAUTIONS**

### FITTING THE BLANKET

The electric blanket should be securely fastened to your mattress. If it is fully fitted with fabric side walls, ensure that all corners have covered the mattress evenly. If it is a tie down electric blanket, make sure it is securely tied down in each corner.

The control/s should be closest to the end nearing the pillow.

If you are using a mattress protector, place it over the electric blanket.

Only use a size suitable for the size of your mattress.

Once the electric blanket is securely fitted to your mattress, connect the plug to the nearest power source and switch on. Ensure that the hand controls are not tucked in to the sides, and are not exposed to moisture.

Only use the controller model type as specified at the back of this manual.

#### **OVERHEATING**

All electric blankets are fitted with our Overheating Safeguard System. This offers protection against overheating or damage to the element by disengaging the power to the heating element before any hazards may occur.

If the product is misused against the instructions provided, the warranty will be voided

CHECK DAILY THAT YOUR ELECTRIC BLANKET IS FLAT, FULLY SPREAD OUT AND SECURED BEFORE SWITCHING ON.

FAILURE TO OBSERVE THESE INSTRUCTIONS WILL CAUSE OVERHEATING.

This will activate our Overheating Safeguard System, or leave the electric blanket inoperative, voiding all warranties.

Do not be concerned if you notice a blue flash in the switch when it is moved from one setting to another. This is NOT dangerous and is only the copper parts making contact.

## **INSTRUCTIONS FOR STANDARD MODELS**

The following instructions are for the following models:

| NZ Super King         SEBK         2x70W           Super King         SEBSK         2x70W           NZ California King         SEBCK         2x70W | Super King |  | 2x70W |
|--|------------|--|-------|
|--|------------|--|-------|

| Single STDEBS |
|---------------|
| Queen STDEBQ  |

### **HOW TO OPERATE**

Once the electric blanket is securely fitted to your mattress, connect the plug to the nearest power source and switch on.

Ensure that the hand controls are not tucked in to the sides, and are not exposed to moisture.

It is recommended that the electric blanket is turned on to setting 3,1-2 hours prior to going to bed, and the setting is lowered or switched off completely when going to bed.

There are three temperature settings; the electric blanket is at it's hottest when the controller is set at the position indicated by three dots.



## **INSTRUCTIONS FOR PREMIUM MODEL**

The following instructions are for the following models:

| Single             | SPEBS  | 70W   |
|--------------------|--------|-------|
| King Single        | SPEBKS | 90W   |
| Double             | SPEBD  | 2x60W |
| Queen              | SPEBQ  | 2x60W |
| NZ King            | SPEBKB | 2x60W |
| King               | SPEBK  | 2x65W |
| NZ Super King      | SPEBK  | 2x65W |
| Super King         | SPEBSK | 2x65W |
| NZ California King | SPEBCK | 2x65W |
|                    |        |       |

#### **BEFORE USE**

When using your electric blanket for the first time, set the body and foot temperatures to 9, and time to 5 hours. Leave the electric blanket to heat and time out on its own.

This process will remove any humidity in the cover and alleviate any odours present from the manufacturing process. Continual use thereafter will then eradicate any odour (if present).

#### **TEMPERATURE SETTINGS**

Turn the On/Off switch to the "On" position.

To set the temperature in the body section, press the button "Body". To set the temperature in the feet section, press the button "Feet".

The temperature settings can be changed by pressing the buttons again turning it to the desired setting (0-9).

It is recommended that the electric blanket is turned on to setting 9, 1-2 hours prior to going to bed, and the setting is lowered or switched off completely when going to bed.

**Warning** - The highest temperature setting (9) is for preheating only and not recommended for continuous operation.

#### TIMER SETTINGS

The "Timer" button can be used to set the operation time, the electric blanket will automatically switch off once it reaches this time. Keep pressing the "Timer" button until it reaches the desired operation time. If the timer has not been set, the standard operation time is 1 hour.



## CARE INSTRUCTIONS

#### PRIOR TO CLEANING

Switch to OFF and ensure the plug has been removed from the power outlet.

If the electric blanket has a detachable controller disconnect it by pulling the triangular tab away from the electric blanket with one hand, and pulling the plug out with your other hand.

The controller cannot get wet or it will stop working.

Before washing, check that the electric blanket is stretched out, maintaining a rectangular shape, and that no heating wires have been squashed together.

# WASH INSTRUCTIONS FOR ELECTRIC BLANKETS WITH FIXED CONTROLLERS

Spot clean in warm water with mild detergent. Press water out while flat with towels. Dry on stable clothesline, do not use pegs.



DO NOT bleach



DO NOT iron



DO NOT dry clean



DO NOT machine or hand wash



DO NOT insert pins



DO NOT use with an infirm person, infant or person insensitive to heat

## WASH INSTRUCTIONS FOR ELECTRIC BLANKETS WITH DETACHABLE CONTROLLERS

Do not wring, press water out while flat. Dry on stable clothesline, do not use pegs.



DO NOT bleach



DO NOT iron



DO NOT dry clean



Cold machine wash on wool or delicate cycle.



DO NOT insert pins



DO NOT use with an infirm person, infant or person insensitive to heat

The connections to the electric blanket should be kept free of moisture as much as possible. Do not turn the blanket on unless it is completely dry.

## TREATMENT FOR LOCALISED SOILING

The affected area should be sponged gently using a natural wool detergent or mild soap flakes in lukewarm water, followed by two dabs of the sponge with clean lukewarm water. Lightly compress the treated area between two towels to absorb excess water.

## WARRANTY INFORMATION

#### WARRANTY

The benefits conferred by this warranty are in addition to all implied warranties, other rights and remedies in respect of the product, which the consumer has under the Australian Consumer Law and similar State and Territory Laws

The original purchaser of this product is provided with the following warranty, subject to the following conditions.

Bambury Pty Ltd warrants this product for a period of 2 years from the date of purchase for all part defects in workmanship or materials. The product will be replaced free of charge.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.

You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Any costs of returning and collecting the product is at the customer's expense. If the item is/becomes faulty, cease using the product and contact the retailer or Bambury Pty Ltd:

Ph:1300 766 762 (Australia) or 0061 8 9418 9000 (If calling from outside of Australia)

Email: info@bambury.com.au

### WARRANTY CONDITIONS

This warranty is only valid for the electric blanket used, washed and stored in accordance to the manufacturer's instructions. The electric blanket must not be modified or changed in any way.

Connection must be to the voltage requirements as specified in the ratings label located on the product/manual.

Bambury Pty Ltd and the manufacturer do not accept liability for any direct or consequential damage, loss or other expense arising from misuse, or incorrect installation and operation of the electric blanket.

Warranty will only be given where proof of purchase is provided, i.e. On the presentation of the original purchase receipt or invoice.

The purchaser should also complete and return the included Warranty Card to the postal address shown soon after the date of purchase.

The electric blanket is designed for domestic use only and not warranted for industrial or commercial use.

#### Note:

No user serviceable parts inside. Unauthorised modifications void warranty.

Return to place of purchase for replacement or repair under warranty.

## BAMBURY

## Standard Electric Blankets (Tie Down)

Approval Number SAA-180079-EA Controller Model: SEBC21

Single STDEBS 60W Queen STDEBQ 2x60W

## Standard Electric Blankets

Approval Number SAA-180079-EA Controller Model: SEBC21

| Single             | SEBS  | 70W   |
|--------------------|-------|-------|
| King Single        | SEBKS | 90W   |
| Double             | SEBD  | 2x60W |
| Queen              | SEBQ  | 2x60W |
| NZ King            | SEBKB | 2x60W |
| King               | SEBK  | 2x70W |
| NZ Super King      | SEBK  | 2x70W |
| Super King         | SEBSK | 2x70W |
| NZ California King | SEBCK | 2x70W |

## **Premium Electric Blankets**

Approval Number SAA-202780-EA Controller Model: SPEBC21

| SPEBS  | 70W   |
|--------|---|
| SPEBKS | 90W   |
| SPEBD  | 2x60W   |
| SPEBQ  | 2x60W   |
| SPEBKB | 2x60W   |
| SPEBK  | 2x65W   |
| SPEBK  | 2x65W   |
| SPEBSK | 2x65W   |
| SPEBCK | 2x65W   |
|        | SPEBKS SPEBD SPEBQ SPEBKB SPEBK SPEBK SPEBK SPEBK |

Made in China for Bambury Pty Ltd ABN: 68 104 570 531 www.bambury.com.au info@bambury.com.au







2 Year Warranty Replacement