



ASSEMBLY GUIDE



ELLI CHAIRS

Elli Chairs & Elli Highback Chairs

The seat part comes made up and is numbered on the side. The leg assembly must have a matching number on the box. Each set has five bolts either side on each side. The longer bolts attach through the armrest to the back of the seat and the remaining bolts attach the legs to the base of the seat. Put all five bolts through the leg/arm assembly first and offer up to the seat knocking the bolts in a little at a time in rotation. It may help to clean all threads after they have been knocked through the predrilled holes before fitting your nuts and washers.

The "FLIP LEG" should now be fitted to the assembled chair. Bolt the two leg extensions to the inside of the back legs using the two bolts provided and the Butterfly nuts (these nuts are threaded on the inside face of each leg). Now attach the flat cross support using the four screws provided (bradawl marks show the position) so it is on to the front side of the back legs. Do not fit the screws too quickly as they may overheat and shear. This therefore acts as a stop when the legs are down for the eating position and swings up and under the seat base when in the relaxed sitting position. (See photo in brochure for extra help).

Elli Steamer attachments

To fit the attachment tilt the Elli chair back onto the back legs and insert the metal straps between the first and second lathes.

Do not stand on the attachment itself.

Carita Bridge

The nature of this piece demands that the joint is close and tight. If the wood is swollen with moisture the bridge may become difficult to slip on. We recommend a rub with candle wax to the running rails which will assist when slipping the bridge on or off the chairs.

DON'T FORGET TO PAINT ON THE FURNITURE PROTECTOR AS SOON AS THE PRODUCT IS ASSEMBLED, UNLESS ANOTHER FINISH IS TO BE APPLIED.