

## TROUBLESHOOTING POWER PROBLEM

1. Check all power is turned off and disconnected from 240 power supply.
2. Stand in front of unit remove middle splashback.  
Go to left hand side of unit. Remove side table leg and side table.
3. Take out power box you will need a 5mm Alan key for the head of bolt and shifter to undo nut off bolt. Hold box with one hand pull out bolt.
4. Lower box to disconnect flat lead which goes 12volt to switch.  
Open top of cover pull off.  
Remove the black power box.

**Return faulty part to us for checking and/or replacing.**



E: sales@proplaster.com.au

### TROUBLESHOOTING GUIDES AVAILABLE

1. Power Box
2. Changing the Bags
3. Changing the Sensors
4. Clean & Warranty
5. Control Box
6. Leaking & Poor Pressure
7. Removing Pump



### FILL OUT BELOW AND RETURN WITH FAULTY EQUIPMENT

#### POST REPLACEMENT PART TO:

C/o Customer Care Department  
31 Neumann Road, Capalaba Qld 4157

- PROOF OF PURCHASE **ENCLOSED/EMAILED.**
- DETAILED EXPLANATION OF THE DAMAGE/ISSUE
- PICTURES/VIDEOS AND ANY OTHER ADDITIONAL MATERIAL TO SHOW THE DAMAGE **EMAILED.**
- DETAILED EXPLANATION OF THE DAMAGE/ISSUE **ENCLOSED/EMAILED.**

The more information you supply, the easier and quicker we will process your request.

Name: \_\_\_\_\_

Phone: \_\_\_\_\_

Return Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Email: \_\_\_\_\_