BAJARACK WARRANTY

This Limited Warranty covers BajaRack products and all accessories for a period of 2 years from the date of purchase to the original owner of the product and does not apply once the equipment is sold or transferred to another person.

This Warranty does not cover the cost of removal of reinstallation or the product. BajaRack warrants (subject to conditions listed in this warranty) all products to be free of manufacturing defects in materials and workmanship.

Warranty claim requirements

The claim has to be submitted during the warranty period at the place of purchase or directly at our corporate office located:



BajaRack Adventure Equipment 2275 Michael Faraday Drive, Suite 6 San Diego, CA 92154 USA Phone Number: 760-621-0171

On your product you will find a label with a serial number. If you remove this label, please save the serial number in a safe place. You will need it if you want to make a warranty claim in the future. Any cost incurred to transport the defective product "to and from" will be the customer's responsibility.



Warranty resolution

Subject to BajaRack inspection of the product, the company will remedy defects in materials and/or workmanship by repairing or replacing, at BajaRack's option, the defective product without charge for parts or labor, subject to the limitations and exclusions described in this warranty. BajaRack may elect, at its option, not to repair or replace a defective product, in which case BajaRack will issue to the original retail purchaser, at BajaRack's option, either a full refund equal to the purchase price paid for the product, or a credit to be used toward the purchase of new BajaRack products or accessories.

Limitations of Liability

BajaRack is not liable for damage caused by shipping or transport of BajaRack products. It is the responsibility of the original retail purchaser to inspect all products prior to acceptance and to notify the shipping carrier in a timely manner so that any claim for damages can be made. If timely notification to the shipping carrier by the original retail purchaser is not made regarding damage caused during the transport of the product, a claim for damages may not be possible, and all liability falls to the original retail purchaser. This warranty does not apply if accident, abuse, misuse, collision, overloading, modification, misapplication, improper installation, or improper service has damaged the Product.

BAJARACK SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, SPECIAL, EXEMPLARY, OR PUNITIVE DAMAGES OR FOR ANY OTHER DAMAGES OF ANY KIND OR NATURE [NO PERIOD.] (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWN TIME OR LOSS OF USE) UNDER ANY LEGAL THEORY, EVEN IF BAJARACK WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BAJARACK'S SOLE LIABILITY IS LIMITED TO THE REMEDY SET FORTH ABOVE.

BajaRack reserves the right to change Product design without notice.






TOYOTA FJ CRUISER

(2007-2017)
OEM BASKET RACK



RACK COMPONENTS



A) Rack	(1x)
B) Top Clamp	(4x)
C) Bottom Clamp	(4x)



D) 3/8" -16 x 2-1/2" Hex Cap Screw Stainless Steel	(4x)
E) 3/8" X 1" OD Flat Washer Stainless Steel	
F) 3/8"- 16 Nylon Insert Lock Nut Stainless Steel	(4x)
G) Grease, for use with all bolts with lock nuts	(1x)



- · 9/16" wrench or ratchet tool
- · 9/16" torquemeter



Tips and recommendations (please read)

- Please Install your rack with the help of a friend.
- Your Rack is an accessory; it is not protection for rollovers

INSTALLATION STEPS

Take out the contents of the box and place on a flat surface. With the help of friend ,place the rack on the roof of the car. Verify that the front of the rack is aligned to the front of the FJ factory rack. (Fig 1).

Fig. 1



Place the top clamps (B) over welded plates and place the bottom clamps (C) below welded plates. Start this step at the front. (Fig 2)

Note: See the figure A and figure B to identify the top and bottom clamps.



B - Top clamp






Fig. 2

C - Bottom clamp


INSTALLATION STEPS


Insert the bolts (1) and the flat washer (2) through top clamp (B), welded plate, and bottom clamp (C). Below insert the flat washer (2) and nylon nut (3).





Note: Hand tighten (not completely). Remember to add some grease (4) on threads of each bolts.







Finally, use torquemeter to tighten to 65 inch lbs.



INSTALLATION STEPS







TECHNICAL SPECIFICATIONS

FJ CRUISER

BR-TYFJ-OEMRCK-48-0 OEM Basket Rack (fits factory rack)





This Rack comes as one piece and includes all mounting brackets, stainless steel hardware, and aluminum wind deflector.

Material and Thickness: 1" (25.4mm) and 1/2"(12.7mm) Steel

tubing

Top Wind Deflector: .062" (1.57mm) 5050-H32 Aluminum Bottom Wind deflector: .062" (1.57mm) 5050-H32 Aluminum Finish: Epoxy primer (rust inhibitor) with black powder coating

Rack weight: 32 Lb (14.51Kg) Weight Capacity: 200 Lb (90 Kg)

Measurements: 38"(965.2mm) front Wldth, 36"(914.4mm) back Width x 48" (1219.2 mm) Long x 5.25" (133.35 mm) tall

Cargo area: 9.96ft² (0.92m²)

Mounting method: Set of Clamps (8 total), no drilling required.

COMPATIBLE ACCESORIES







Fuel Can Holder

Axe & Shovel mount for Toyota FJ factory rack

Awming mount for Toyota FJ factory rack



Hi-Lift mount for Toyota FJ factory rack



Light Clamp mount



Maxtrax mount for Toyota FJ factory rack



Tent Plates



Solar panel mount



Tire mount



Water Can Holder



Yakima & Thule Accessory mount (2 pieces)



Yakima & Thule Accessory mount (4 pieces)



Light Bar for Toyota FJ factory rack