

Wheel Stop Installation Instructions

AB-WS-1650

Parking Direction	Wheel Stop distance to front of parking space			
	Parking to kerb ≤ 150 high		Parking to kerb > 150 high or wall	
	Wheel Stop Height		Wheel Stop Height	
	90	100	90	100
Front - In	630	620	830	820
Rear - In	910	900	1110	1100