



B110 Pole Bag User Instructions

Thank you for your purchase!



Fig.1



Fig.2

1. Open the pole Bag, put your pole in. Fig.1
2. Fold over the excess flap and secure with the buckle and web. Fig.2



Fig.2



Fig.3

3. Thread the 303 Rolie Side webbing through the slots in the "Daisey Chain" on side. Fig.3
- 4 Tighten securely.

If you have any questions or need assistance please call us at: (800) 535-8131 Or email us at info@wolfmanluggage.com
Happy Riding. Woofle