



**See reverse for summary of demonstration mode**

## Demo Mode

(Hold hand in front of gWave™ sensor for seven seconds to initiate demo mode; heater will begin after 3 seconds, **continue holding and unit will beep 3 times to confirm demo mode**)

1. Start demo mode
2. ComfortSaver™ Ceramic Heating System
  - Set temperature increases - 72 °F, 73 °F, 74 °F, 75 °F
3. Heat Boost (maximum heat output)
4. Eco Mode (reduces heat output for energy efficiency)
5. Timer
6. Multi-Fire XD Lighting Themes:
  - Wood fire
  - Gas fire
  - Red
  - Blue (full brightness)
    - Blue (low brightness)
    - Blue (full brightness with flickering effect)
    - Blue (low brightness with flickering effect)
  - Prism (scrolls through all colors)
  - Kaleidoscope (scrolls through multiple colors at the same time)
  - Personal
    - Red (zero to full intensity to zero)
    - Green (zero to full intensity to zero)
    - Blue (zero to full intensity to zero)
    - Teal (customized color as an example)
7. End demo mode (unit will beep 3 times to confirm end)