LOG PLACEMENT GUIDE

DESIGN-MEDIA-6PCE

Palisade Emerson Newcomb Langley



- 1. Shut off gas and electrical supply and allow the unit to cool to room temperature.
- 2. Remove glass and safety barrier
- 3. Carefully open Designer Media Kit box and gently remove the logs and media. The logs are fragile.



4. Add the desired amount of black fireglass and/or pebble decorative media to the burner tray.

Before you begin:

Read the instructions carefully and refer to the examples in the images below. Do not use broken logs.

You will find there are more log set pieces in the box than can be used. Every precaution has been taken to ensure the log sets are not damaged in transit - but in the event that there is some breakage there will be extra pieces to use in their place.

WARNING: Improper positioning of the logs may create carbon build-up and can alter the units performance which is not covered under warranty.

DO NOT PLACE LOGS DIRECTLY ON OR OVER

FLAMES. Logs must be placed to avoid the flame completely. See examples below.



Black fire glass



90-piece pebble



9-piece rocks

5. Place logs as desired avoiding the flame tray as in examples below



Langley



Palisade & Newcomb



Emerson



embers 1

embers 2







embers 3

embers 4

6. Install decorative vermiculate embers over glass and pebbles as desired.