


SPINSHOT™ Pro Pickle User Manual



BASIC INFORMATION:

- Basic speed of the machine:10-60mph.
- Knob sets the speed, rotation, and delay of each incoming ball.
- Random oscillation mode, can be randomly sent at any angle.
- Set the service interval 1-10 seconds at will
- The net weight of the machine is 40lbs, 47lbs including battery.
- Ball Capacity: 85

SAFETY & MAINTENANCE:

- The wheels spin at high speed. Never put your hands in the machine or stand in front of it when they are spinning.
- DO NOT put foreign object into the hopper. This can cause blockage and damage to the feeder motor.
- Keep hands clear of the hopper tray, which turns with significant force.
- Do not use wet balls.
- Do not store outdoors.
- For troubleshooting, see <https://spinshotsports.com/pages/troubleshooting>