



TX-ZVS-3 Remote Control *(303MHz or 433MHz)*



Programming Remote Controls

1. Open the Driver's Door
2. Turn the Ignition ON, OFF, ON, OFF, ON, quickly. (if siren fitted, the siren will chirp once)
3. Now hold the emergency override button down until the siren chirps 3 times then release.
4. Press button #1 on the transmitter. (if siren fitted, the siren will chirp once)
5. Press button #1 on the 2nd transmitter. (if siren fitted, the siren will chirp once)
6. Press button #1 on the 3rd transmitter (Optional) – (if siren fitted, the siren will chirp once)

Note: Up to 3 remote transmitters only can be programmed.

To exit code learning mode, simply turn the Ignition OFF.