

Care instructions Aeris Swoppster

Polyester cover:

The cover is removable and can be washed at max. 40°. We recommend using a mild detergent and not using fabric softener – also for the sake of the environment.

Cleaning of the foot ring:

Clean the foot ring and the protective cover with a damp cloth, if necessary with a little pH-neutral soap. Then, rub down with a dry, clean cloth.