

04 / LED status

LED Status		Specification
Off	The amount of food is more than 10%	Model: PF005 Power Input: 5V 1A Capacity: 2,6 L (1,2 kg) Size: 191x191x315 mm (7,52x7,52x12,40 inches) Communication: Wi-Fi (2.4 GHz) Range: 30m (98.5 feet) Net Weight: 1,55 kg Warranty: 1 Year
Fast blinking red	The amount of food is less than 10%	
Steady red	Jam	


05 / Precautions

1. Please use it in the indoor environment;
2. Do not drop anything other than dry food into the food hopper. Otherwise, there is a risk of dysfunction or mistaken feeding;
3. To prevent feeder from being hit by pets, it is recommended to place the feeder at the corner or against the wall;
4. Please shield or organize the power cord well to prevent the pet from biting the cable and causing dangerous situations such as electric shock;
5. Do not disassemble or modify the device yourself;
6. This product is only suitable for DRY FOOD, and WET FOOD is prohibited.
7. The pet food's shape and density will cause some deviations from the food hopper's capacity and the feeding unit's quantity.
8. After each fill-up of the hopper, there may be deviation of two portions at the initial feeding time. It is recommended to calibrate manually! (Click the manual feeding button until food is fed!)
9. Clean the food passage regularly to get the kibble out smoothly.
10. DO NOT clean the main unit; instead, please wipe it with a rag. After cleaning the other parts, please dry it before reinstalling.
11. Children must use under the guidance of adults.

06 / Warranty Terms

Within the period of warranty, if the product fails with no fault of user operations, it will be repaired at Pettadore their expense. The warranty will not cover product failure in examples below:


- 1) Intentional damage to the product by the user or third party.
- 2) Failure to operate or maintain the product following the (QIG) Quick Installation Guide Instructions.
- 3) Failure by natural wear and tear including but not limited to scratching, corrosion, oxidation and rusting.
- 4) Failure by non-authorized repair of the product including but not limited to user's own or third-party repairing attempts or modifications.




! For other languages see pettadore.com/pages/manuals !

All pictures shown in the manual are for illustration purposes only. Actual products may vary due to product enhancement.

01 / Meet your Nutri Fresh




Contents of the box



02 / Operations


1) Power on the feeder

Unbox and connect the Micro USB cable to the power input port at the bottom of the feeder, then connect the A/C adapter to the wall outlet.




3) Lid removing

Open the lid according to the marked direction.




2) Bowl mounting

Slide the bowl into the feeder's outlet.



4) Fill the desiccant


Remove the desiccant from the packaging and place it in the desiccant cabinet.



* It is recommended to replace the desiccant once a month. Don't let it fall into the hopper, and NEVER use it if it is damaged.


5) Fill the hopper with food

Pour food into the hopper and fill it




7) Manual feeding

Short press the manual feeding button to feed instantly. *Default quantity is one portion, customizable through the App.




6) Lid closing

Lock the lid according to the marked direction



8) Connect feeder with your phone and schedule your feeding


Download the Pettadore App and connect the feeder to your Wi-Fi to schedule your feeding



Backup Battery Installation

Use a screwdriver to open the battery compartment cover at the bottom. Put four LR14 batteries inside (note the positive and negative poles), replace the cover and tighten the screws.

Note: You need to buy the batteries separately, and only alkaline dry batteries are supported. Before installing, make sure that there is nothing in the battery compartment. Install batteries for emergency backup in case of power failure. If the batteries are not used for a long time, please remove the battery.



03 / Quick Setup

1. Scan the QR code on the right and download the Pettadore App which is available on App Store and Google Play. Click Sign up to get walked through to create your Pettadore account.



2. Power on and ensure the Wi-Fi Indicator LED is blinking fast reflecting the device is ready for joining the Wi-Fi. Open the Pettadore App and click the '+' button and get walked through the SET-UP steps.

Notice:

- The feeder doesn't support the 5GHz Wi-Fi, please make sure your Wi-Fi is 2.4G.
- If the Wi-Fi indicator is not blinking fast after power-on, please long press and hold the button until the indicator blinks quickly.