

P-51 MUSTANG

JUBILEE AUTOMATIC

For more infomation Pour plus d'informations Para más información Per maggiori informazioni Für mehr Informationen 想要查询更多资讯 詳細については



Instruction Manual

Vol. 1.87 EN

AV-4087

© AVI_8

For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM



AUTOMATIC WATCH

This timepiece is equipped with a self-winding Mechanical Automatic

It does not need a battery.

It is powered by the motions of the user's own wrist during the wear of the watch. You may also choose to wind the watch manually.

For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM

HOUR HAND HAND CROWN AUTOMATIC DATE SECÓND HAND (1ST CLICK) (2ND CLICK) CLOSED FOR WATER RESISTANCE FOR WATER RESISTANCE

]

Before you use this watch, it is recommended that you manually wind the mainspring to start it moving.

This watch is an automatic watch equipped with a manual winding mechanism.

WINDING THE MAINSPRING




When it is in position [0], turn the crown clockwise to wind. Wind 5-10 times and it will start to move naturally after shaking slightly.

* This watch MUST be worn for at least 8 (Eight) hours each day to ensure it is fully wound. An automatic watch will only wind when the watch is on your wrist and your arm moves. Winding the watch by the crown will put power on the spring but not enough to allow the watch to function fully. If your watch stops overnight or loses time it means it is not being fully wound.

3 4

HOW TO SET THE TIME


- 1. Pull the crown out to position [2]-(2nd click).
- 2. Turn the crown clockwise to set the correct time.
- 3. Push the crown in.



* Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.


HOW TO SET THE DATE

- 1. Pull the crown out to position [1]-(1st click).
- 2. Turn the crown anti-clockwise to set the correct date.
- 3. Push the crown in.



* Do not set the date between 9:00 P.M. and 4:00 A.M.


HOW TO CHANGE THE BRACELET TO LEATHER STRAP



7

HOW TO USE A DEPLOYANT CLASP





- 1. Flip the cover.
- 2. Press the buttons on the clasp sides.

WATER RESISTANCE

The water resistance indicated on your timepiece serves only as a guide. Actual water resistance may vary depending on a number of important factors including temperature, water salinity, and actual use under water.

The water resistance of your timepiece may eventually be compromised over time with general wear and tear and the use of your watch under adverse conditions.

Always remember to employ the screw down crown (if available) to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed. Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch.

The steam may cause condensation inside your watch, which may affect and damage the inner workings of your watch – which would also not be covered by the warranty.