

⊙ AVI_8

FLYBOY

ROYAL BRITISH LEGION TRI-SERVICE CHRONOGRAPH

LIMITED EDITION

For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM



For more infomation Pour plus d'informations Para más información Per maggiori informazioni Für mehr Informationen 想要查询更多资讯 詳細については



Instruction Manual

Vol. 1.102_RBL EN

AV-4102


CHRONOGRAPH WATCH

Meca-Quartz Chronograph

This watch is powered by a Japanese made "Meca-Quartz" movement. It combines a battery regulated engine with a mechanical chronograph module. The result is a watch which delivers the meticulous pinpoint precision of a quartz movement along with the crisp, flyback handfeel and visual charm of mechanical watches.


For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM



HOW TO SET THE TIME


- 1. Pull the crown to position [2]-(2nd click).
- 2. Turn the crown clockwise to set the correct time.
- 3. Push the crown in.



- * Take A.M./P.M. into consideration when setting the hour and minute hands to the desired time.
- * When the crown is at the position [2], do not press any button, otherwise the chronograph hands will move.

HOW TO SET THE DATE

- 1. Pull the crown to position [1]-(1st click).
- 2. Turn the crown clockwise to set the correct date.
- 3. Push the crown in.





* Do not set the date between 9:00 P.M. and 3:00 A.M., otherwise the day may not change properly. If it is necessary to set the date during the time period, first change the time to any time outside it, set the date and then reset the correct time.

STOPWATCH FUNCTION

• The stopwatch can measure up to 12 hours.

ACCUMULATED ELAPSED TIME MEASUREMENT







Restart and stop of the stopwatch can be repeated by pressing the button A.


HOW TO USE INNER BEZEL TO CHECK ELAPSED TIME


- 1. Turn the upper crown anti-clockwise, the inner bezel turns clockwise.
- 2. Align the mark " 60 " of the inner bezel with the position of minute hand (white minute hand).
- Then read the scale above the inner bezel, to which the minute hand points so as to figure out the elapsed time (gray minute hand).



HOW TO CHANGE THE LEATHER STRAP TO NATO STRAP







7.



11

WATER RESISTANCE

Note that the water resistance chart serves only as a guide (please refer to the water resistance chart on the next page). Actual water resistance may vary depending on a number of factors including water temperature, water salinity and use under water. The water resistance of your timepiece may eventually be compromised over time with general wear and tear and use of your timepiece under adverse conditions.

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch. This may cause condensation inside your watch, which may affect and damage the inner workings of your watch.

WATER RESISTANCE CHART	50M/ 5ATM
SPLASH/ SHOWERING	\bigcirc
SWIMMING/ BATHING	\bigcirc
BRIEF SWIMMING/ WATER SPORTS	\otimes
PROLONGED SWIMMING/ FREE DIVING	\otimes
SCUBA DIVING	\bigotimes
PROFESSIONAL DEEP SEA DIVING	\otimes

Represented By: Authorised Rep Compliance Ltd., Ground Floor, 71 Lower Baggot Street, Dublin, D02 P593, Ireland.

AWARNING

- INGESTION HAZARD: This product contains a button cell or coin battery.
- DEATH or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.



- · KEEP new and used batteries OUT OF REACH of CHILDREN.
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.

