NİTHO

NX120

STEREO HEADSET WITH FOLDABLE MICROPHONE



Model: SND-NTXC-K

QUICK START GUIDE

Thank you for purchasing NX120


This Quick Start Guide is designed to help you through installation

Please register your product to benefit ONE ADDITIONAL YEAR WARRANTY EXTENSION.

To benefit your warranty extension please visit https://www.nitho.com/registration and follow the instructions on the screen

CONTROLS

This headset has been designed to work with devices using a standard 3.5mm headset port.





WARNING

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Settings > Devices > Audio Devices > Output to headphones > 'All Audio'. Set Input and Output Device to 'Headset Connected to Controller'.



All Settings > Display & sound > Volume > Chat mixer > Mute all other sounds > Party chat output > Headset.

*Controller has a headset port: Headset Adapter Not Required



*Controller has no headset port: Headset Adapter Required



Microsoft Stereo Headset Adapter (Not included)



Check the application settings that you want to use and select the headset for use.



PC's with Mic & Audio ports will require a PC splitter cable.



PC splitter cable (Not included)

SERVICE & SUPPORT

For any question and support request, contact us on support@nitho.com or visit our website www.nitho.com











Despite careful review of the contents, errors and omissions are excepted. All specifications are subject to change without notice.

PlayStation4/PS4, and PlayStation Move are registered trademarks of Sony Computer Entertainment Inc. XBOX ONE is registered trademarks of Microsoft Inc. Nintendo Switch is registered trademarks of Nintendo Inc.

The products enclosed are not sopnosred, endorsed by, or manufactured for Sony Computer Entertainment Inc., Microsoft Inc., or

NiTHO GmbH - Victoriastrasse 3b - 86150 Augsburg - Germany

Nintendo Inc. respectively.