

Cleaning Recommendations: Percussion Guns

XLR8 Cleaning

- XLR8 handle and gun: wipe down with light soap and damp cloth or cleaning wipes. Any cleaner your team uses on equipment upholstery (seats, seat backs, etc..) will work great
- Thumb, Plate, Y, Point, Apollo: general use cleaning wipes or soap and water
- Ball: water only
- Make sure all attachment stems are dry prior to re-inserting them into the XLR8.
- Be careful not to puncture attachment heads
- Be cautious around white mesh, main body, as this will directly go into the motor housing.
- Do not submerge your XLR8 in any fluid
- Do not get the upper portion of your XLR8 wet
- Do not use any harsh chemical cleaners on your XLR8
- Do not spray liquids directly on your XLR8; use a towel or wipes



XPRS Cleaning

- Body of XPRS gun: wipe down with light soap and damp cloth or cleaning wipes. Any cleaner your team uses on equipment upholstery (seats, seat backs, etc..) will work great
- Plate, Y, Point: general use cleaning wipes or soap and water
- Ball: water only
- Make sure all attachment stems are dry prior to re-inserting them into the XPRS
- Be careful not to puncture attachment heads
- Do not submerge your XPRS in any fluid
- Do not use any harsh chemical cleaners on your XPRS
- Do not spray liquids directly on your XPRS; use a towel or wipes

