derlot®

Care & Maintenance Guide

Here are our recommendations for maintaining your Derlot product; following them regularly will aid in keeping your product in good condition.

Take caution when specifying the finish for products to be used in particular environments such as high traffic areas. Lighter colours will show dirt and wear more readily than darker ones, and will require a more frequent cleaning routine.

· Solid Timber, Veneer & Plywood

Avoid continuous exposure to direct sunlight and moisture. Wipe surface along the grain of the timber with a soft cloth dampened with a detergent and warm water mixture. Do not overly wet the surface. Avoid bleaches, acids, alcohols or abrasive materials. Dry the surface thoroughly with a clean soft cloth after washing. Treat spills and stains as soon as possible.

Avoid placing hot items directly on the surface. Do not drag items directly across the surface, and use placemats and coasters to avoid scratches.

Laminate

Avoid continuous exposure to direct sunlight and moisture. Wipe surface with a soft cloth dampened with a detergent and warm water mixture. Do not overly wet the surface. Avoid bleaches, acids, alcohols or abrasive materials. Dry the surface thoroughly with a clean soft cloth after washing. Treat spills and stains as soon as possible.

Avoid placing hot items directly on the surface. Do not drag items directly across the surface, and use placemats and coasters to avoid scratches.

Powder coated metal

Clean with a soft cloth soaked in a detergent and warm water mixture. Avoid bleaches, acids, or abrasive materials. Rinse and dry the surface thoroughly with a clean soft cloth after washing. Remove any remaining film or residue with hot water.

Brushed stainless steel

Wipe surface along the grain of the steel with a soft cloth dampened with a stainless steel cleaning agent. Avoid bleaches, acids, or abrasive materials. Dry the surface thoroughly with a clean soft cloth after washing.

Polished stainless steel

Dust regularly. Remove dust and dirt particles with a duster before cleaning, as these may cause scratches if caught in a cloth. Wipe surface lightly with a soft cloth dampened with a stainless steel cleaning agent. Avoid bleaches, acids, or abrasive materials. Dry the surface lightly with a clean soft cloth after washing.

• LDPE & HDPE plastic

Regular cleaning of LDPE & HDPE plastic will help minimize the build up of dirt and grime. We recommend using Extreme Simple Green® Aircraft & Precision Cleaner, along with a scrub brush. Please follow the manufacturer's instructions and ensure all precautions are followed. Treat spills and stains as soon as possible.

Treatment of the surface prior to use, along with treatment reapplication at regular intervals, will also aid in preventing buildup of dirt and grime. We recommend DuPont™ Non-Stick Dry-Film Lubricant with Teflon®. Please follow the manufacturer's instructions and ensure all precautions are followed.

Acrylic

Dust regularly. Remove dust and dirt particles with a duster before cleaning, as these may cause scratches if caught in a cloth. Wipe surface lightly with a soft cloth dampened with a detergent and warm water mixture. Avoid bleaches, acids, or abrasive materials. Dry the surface lightly with a clean soft cloth after washing.

• Fabric & Leather

Please follow the instructions provided by the manufacturer of your chosen textile.

1