



CARE MANUAL

Luxxbox acoustic products are extremely durable and require little attention to maintain their good looks. Light cleaning on a regular basis, will maintain their appearance and prolong the life of the material.

DO

- Treat stains and soils immediately.
- Wipe lightly with dry microfibre cloth to avoid dust collection.
- Protect from direct sunlight.
- If needed, vacuum using low suction and a smooth attachment.

DON'T

- Do not use abrasive sponges or cloths.
 - Do not use excessive pressure. Avoid severe abrasion.
 - Do not saturate the fabric or interior with water or other cleaning liquids.
 - Do not use dishwashing or laundry detergents.
-

SPOT CLEANING ON PET & WOOL

Treat stains as soon as possible. Gently scrape off any liquids or hardened residues from the surface. Do not scrub.

- **LIGHT STAINS:** carefully dab with an upholstery shampoo and a clean damp cloth or sponge. Always use a branded upholstery shampoo.
- **GREASY STAINS:** use appropriate dry cleaning detergent or solvent. In all cases, we recommend testing stain-removal agents on an inconspicuous area first, to see if there are any effects visible.
- **LARGE, HEAVY STAINS:** professional cleaning is recommended.

