

# Children's Teepee Tent Instructions

1. Remove all of the pieces from the box and place them flat on the floor.



2. 4 of the wooden poles have holes in one end. Join a pole with a hole at one end, with a pole without a hole, using a tubular shell. Repeat 4 times.



3. Thread the wooden poles into each of the four corners of the Teepee fabric tent. Ensure the hole in the poles is at the top of the teepee.



4. Weave the rope through and around the holes and poles to secure the four poles together.



5. After all four poles are firmly tied together, spread the bottom of the four poles as square as possible.

