

www.betron.co.uk



INSTRUCTION MANUAL



- www.betron.co.uk
- https://www.facebook.com/betronstore
- https://twitter.com/betronstore



Dear Customer

Thank you for using KB-S08 Bluetooth speaker. Please read the user manual carefully for proper instruction to maximize the advantage of our product. Our Bluetooth speakers are well designed, fashionable, smart and portable, pure acoustic and multi functional. We have patents for the whole series happy lift: It may provide you the best enjoyment of music an y time at home, outdoor or business work, and lead you to wonderful music, enjoy healthy & happy life.

Cautions

- Please keep or use this product at normal temperature;
- Do not expose this product in rain, To extend it's lifespan please dry in shade after get wet.
- Do not throw this product to aviod any damage;
- Do not disassemble, repair or reform this product;
- Do not clean this product with any chemical solvents;
- Please use USB power of DC5V for output when needed;
- Please follow the instructions of matched battery; do not throw away or put it in fire to avoid any danger.

Tips

- For your health and longer lifespan of this product, please do not play it with high Vol for long time as it will harm your ear.
- In public, please switch it to play in your ear phone, thus will not disturb others.
- Due to its complication, the lithium battery is built-in designed for this product highly improving the safety with less power consumption.
- When an error occurs, please turn it off and pull out the USB socket to avoid any damage to other components.
- The warranty card is not applicable for any deliberate disassembling.

Product Description

Item: KB-S08 Bluetooth Speaker

Bluetooth standard: V3.0

Working range: Up to 10M

Charging power: Power adapter output (DC5V 500mA)

Battery size: 600mAh

Profiles supported: Headset / handsfree /A2DP/AVRCP

Playing time: Up to 4 hours

Standby time: Up to 130 hours

Product size: 61mm x 61mm x 59mm

Product size: 250g

Accessories: Mini 5pin USB & Audio combinedcable,

User manual, Guarantee card

- This product can be applied to audio from any Bluetooth devices like Bluetooth mobile phones, Bluetooth notebooks.
- When being connected to Bluetooth DONGLE on PC, it can play any audio files on the computer.



Product Schematic



Mini 5pin USB charging port




- Power on-switch to " OFF "
 Power off-switch to " ON "
- Pairing-power on speaker to Bluetooth mode, search on the Bluetooth device to find "KB-S08" (enter the pin code 0000 if need, some phones do not need to enter a password) and confirm, then your speaker is connected to the Bluetooth device.
- Voice dialing-On the status of standby ,double press"►II"
- Play/Pause-Press "►II"
- Previous/next track-Short press " " switch to previous track, short press " + " switch to next track
- Answering a call-When there is a call, short press"►∥ " and you can talk on the speaker
- Ending a call-During the call ,short press "►II" and the call will be ended .
- Rejecting a call-When there is a call, short press" | I and the call will be rejected.
- Last number redialing-On the status of standby, press" + "
 for about 2 seconds, it will dial the last number you have
 dialed. (your phone must support the function.)

- Volume control-Long press " + " or " " volume will up or down, there will be a prompt voice when on the loudest sound.
- Charging status-Red light remains when charging, the light is off when charging completed.

Voice Prompt

- —O When turning on speaker, there will be an automatic voice prompt.
- When turning off speaker, there will be an automatic sound.
- O Speaker will have pairing sound automatically when it's in pairing mode.
- Speaker will have paired sound automatically when it's paired successfully.
- —O Speaker will have disconnected sound automatically when connection breaks with other device.

Remark: To use the above function, your mobile phone must support Bluetooth handfree mode 1.5, and the call waiting function of your mobile phone is on.



Radio Function-Power on the speaker, it'll be Bluetooth mode, short press "Multifunction key" will change to FM radio mode, press "+" or "-" to change the channel.

Note: Some phones do not need to enter the password



Handling of the Waste Electrical

The waste Electrical

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly topromote the sustainable reuseof material resources.

Household user should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recycling.





Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

After service

(A) Service system

- 1.Consultancies: Please read this user manual carefully before using this product. For any problem during using it, you can either contact the local retailer or call our customer service
- 2.Exchange service: within exchange time limit, for any indeliberate error during proper use, making sure the product as well as its accessories and package are all not damaged (if the appearance is damaged, it can only be repaired) you can either have it exchanged for a new one or repaired after the error is tested and examined;
- 3.Warranty service: within the warranty time limit, for any indeliberate error that occurs during proper use, warranty service is free for no charge (the speaker has warranty service for free within one year; for any deliberate damage, the warranty service should be paid).
- 4. Charged warranty service: within three years counting from one year after the date the product was purchased, any error repair will be charged; and user should pay the repair components, freight and labor cost.

- 5.Any of the below situation is not in the warranty service, but we provide charged service:
 - 1 The warranty date is expired;
 - ② The warranty card is altered, or the series number differs from that of the product;
 - ③ Accidental or deliberate damage is done to the product (for example: improper use against the user manual, improper set up which causes error, plugging in unmatched power, exposed to water, fallen etc.)
 - ④ cannot provide valid warranty card or invoice (other but can prove that it is within the service limit);
 - ⑤ Any error damage caused by force majeure such as earthquake, fire, flood, lightning strike etc.
 - ⑥ Deliberate assembling, repair or reform without permission from our company.

(B) Explanation of After Service:

- 1.The date of purchased should be in accordance with that of the invoice, any failure to provide the valid proof, is subjected to the production date.
- Quality problem does not include user's personal preference to tone and timbre.
- 3. The shell and user manual package are exclusive to warranty service.
- 4.For the model that production has been stopped, we only provide functional repair.
- 5. We are not responsible for any promises by retailer other than our company.