



LIINII Group Pty Ltd TA LIINII® 148A Albany Street, Point Frederick, NSW 2259, Australia

Assembly and Usage Instructions Product: LIINII Lite™ Stroller

Model #: LSL-0001

A WARNING

Please follow these instructions carefully before using the stroller for the first time. This will help guarantee safe usage of the product and enable you to find out about all its handy features.

- 1. Never leave your child unattended.
- ALWAYS keep the seat backrest completely FLAT
 or INCLINED for children under 6 MONTHS. Children 6 months
 and under may be seriously injured if the seat is not fully reclined.
- 3. Never lift the stroller/pushchair with the child inside it.
- 4. Never adjust the stroller while your baby is inside it.
- 5. Ensure that all the locking devices are engaged before use.
- 6. To avoid injury, ensure that your child is kept away when unfolding and folding the stroller.
- 7. Do not let your child play with the stroller.
- 8. Always use the stroller restraint systems. The harness strap is located on each side, beside the seat belt.
- This stroller is not suitable for running, jogging, skating or any other sport activities.
- 10. Not suitable for overnight sleeping, your child may be at risk of serious harm or injury.
- Any load attached to the handle, backrest or sides affects the stability of the stroller/pushchair.
- 12. To avoid the risk of suffocation, keep all plastic bags and packaging out of reach of babies and young children.
- 13. Never use stairs or escalators with your child in the stroller/pushchair.
- 14. Always check that the brake is fully engaged before letting go of the stroller.
- 15. Never let your child climb into or out of the stroller alone.

- 16. This stroller is suitable for children from newborn to 48 months.
- 17. Keep this stroller away from fire!
- Check that the stroller body or seat unit, seat attachments or devices are correctly engaged before use.
- 19. Maximum permitted weight for the stroller 22kg. Maximum permitted weight for the storage basket is 8kg.
- 20. Always use the tether strap when using the stroller.

AFTER OPENING THE STROLLER BOX:

Make sure your surrounding is clear and keep all plastic and packaging bags out of the reach of children and dispose of them IMMEDIATELY.

IMPORTANT: Always keep plastics, small parts, and loose items away from children to help avoid and eliminate suffocation and choking hazards.

Parts List:



FOLDED: L 56CM X W 48CM X H 25CM

UNFOLDED: L 60CM X W 48CM X H 107CM

B


- 1. Canopy
- 2. Seat
- 3. Bumper
- 4. Safety Buckle
- 5. Leg Rest
- 6. Footrest
- 7. Front Wheel

- 8. Handle
- 9. Shoulder Pad
- 10. Rear Wheel
- 11. Handle Released Button


15. Brake Lever

- 12. Hidden Pocket
- 13. Adjustable Button
- 14. Basket

I. ASSEMBLING:















Unfold the stroller: See Pic 1, hold the handle and press button 1 and button 2 at the same time, and lift the handle until you hear "click", then open the stroller completely as Pic 3.


Assemble the rear wheels: See Pic 4, insert the rear wheels axles into both stroller leg openings until fixed.

Assemble the front wheels: See Pic 5, insert the front wheels axles into both front leg openings until fixed.

Assemble bumper bar: See Pic 6, insert the bumper bar pin into the two opposite openings until fixed.

Extend the canopy cover as shown in Pic 7.


II. USAGE INSTRUCTIONS:




Adjusting the backrest:

See arrow 1, press the adjustment button to adjust the seat to lower position.

See arrow 2, lift the D ring shown in number (2) to adjust the seat to the higher position. You can adjust the seat position according to your needs.






Adjust footrest: See Pic 2, press both side buttons to lower position.


See Pic 3, lift the footrest to higher position.






Use Canopy: See Pic 4, pull the hood forward to open the canopy.


See Pic 5, push the hood back to close the canopy.






Using the brakes: Lift the brake lever to release as Pic 6.


Press the brake lever to lock as Pic 7.






Detaching the front wheels: See Pic 8, release the button to detach the front wheels.

Detaching the rear wheels: See Pic 9, release the button and pull out to detach the rear wheels.






Detaching the bumper bar: See Pic 10, press both side buttons and pull out the bumper bar.

Using the safety harness: See Pic 11, press the buckle first, then adjust the harness length.

NOTICE: USE THE HARNESS BELT CORRECTLY AT ALL TIMES.



Folding the stroller:

See Pic A, hold the handle and press button 1 and button 2 at the same time, push down as shown in Pic B, and the stroller will start auto-folding as in Pic C.

III. USAGE WARNING:

Regularly check screws, rivets, bolts & fastenings to ensure they are locked tight and secured.

Be careful not let the child climb out of the guardrail or stand on the stroller seat.

Do not use the stroller in dangerous areas such as hilly and slopy grounds, or near the hot stove.

Avoid using or storing in a wet, cold, or high temperature environment and keep far away from fire or a source of fire.

Always follow the manufacturer's instructions when using the stroller.

Any load attached to the handle and/or on the back of the backrest and/or on the sides of the stroller will affect the stability of the stroller.

This stroller must be used only for one child for which it has been designed.

Accessories which are not approved by the manufacturer must not be used.

Be careful not let the child climb out of the guardrail or stand on the seat.

IV. MAINTENANCE:

To avoid risk of injury to your child, please check and maintain the stroller regularly.

Cleaning the fabric: Use soft brush or other cleaning tools. Other parts: Use the home-usage washing soap or wipe clean with water and damp cloth.

Check whether there are loosen screws, damaged parts, crack, or tear in the fabric, if necessary, replace the bad ones, do the rehabilitation strictly and according to the manual instructions.

36 Months Australian Manufacturer Warranty on Strollers

Damages and Warranty

Please inspect your order once received and contact us immediately if any item is defective, damaged or if you received the wrong item, so that we can evaluate the issue and make it right.

All strollers come with a three-year manufacturing warranty on the stroller's frame, chassis, and its non-removable parts.

All accessories do not have a manufacturing warranty but are covered under the automatic guarantee as described under the Competition and Consumer Act 2010 also known as the Australian Consumer Law (ACL).

The Warranty period starts from the date that your stroller and all accessories are dispatched from our warehouse, and it is valid in Australia only.

The warranty is not valid and does not cover in the following cases:

- Defects or faults resulting from improper assembly, care or use as outlined in our user manual.
- Defects or faults resulting from an accident, airline, or transport damage.
- Normal wear and tear, including scratches to the frame or color fading of the fabric.
- Minor cosmetic scratches or blemishes resulting from shipping.
- Damage to handle/belly bar grips or fabrics (i.e. scuffs or tears) as a result of normal handling and daily use;
- Corrosion, mold or rust due to extreme environmental conditions, including high humidity, salt spray, snow or due to lack of regular maintenance.
- Products that are purchased second hand or from an unauthorized distributor.
- Using a part or accessory that is not compatible with the product and/or not manufactured or recommended by LIINII Prams and Strollers.
- If you or a third party has attempted to modify or repair the stroller without having received written permission from LIINII.

- Claims from anyone other than the original purchaser (i.e. no longer valid if you gift or sell to your sibling or friend)
- Damage resulting from extreme heat conditions (i.e. leaving in a car on hot days)
- Customer dissatisfaction with the product in terms of fit, weight, functionality, color, or design. Inner tube tyre punctures, tyre bulges or broken air valves.
- Defects to the product caused by accident, neglect, misuse or 'Act of God'.

What if I need to make a claim?

- 1. Contact us by email at enquiries@liinii.com.au and we will respond and start your warranty claim within three business days of receiving your warranty request.
- 2. Include your order number, a detailed description and photo or video of the defect or problem.
- 3. Our warranty team will then determine the best way to resolve any defects or faults. LIINII reserves the right to repair, exchange or replace the damaged item with a replacement part in cases of minor defects. Some parts may be replaced with newer model parts as the stroller is improved over time.

NOTE: This warranty is an additional benefit to your legal and consumer rights under the Australia Consumer Law also known as Competition and Consumer Act 2010 (ACL).

By purchasing a LIINII product means you are agreeing to our warranty agreement and any other policy or terms and conditions stated thereof by us.

Australian Consumers:

This warranty does not infringe on your legal rights and your rights under the Australian Consumer Law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

LIINII Group Pty Ltd ABN 68 624 588 290