

JAMES MCCABE

BELFAST ♦ LONDON

INSTRUCTION MANUAL





Vol.1.51 EN

COLCHAM CHRONOGRAPH

This watch is equipped with a quartz powered chronograph movement. Besides the normal time read out, this movement enables split timing micro measurements of time at the push of a button, which can be utilized in a variety of applications.


For more details on operating this Chronograph please refer to the enclosed booklet or visit

im.mccabewatches.com



HOW TO SET THE TIME

1. Pull the crown to position [2]-(2nd click).
2. Turn the crown clockwise to set the correct time.
3. Push the crown in.




- * Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.
- * When the crown is at the position [2], do not press any button, otherwise the chronograph hands will move.

2

HOW TO SET THE DATE

1. Pull the crown to position [1]-(1st click).
2. Turn the crown anti-clockwise to set the correct date.
3. Push the crown in.




- * Do not set the date between 9:00 P.M. and 1:00 A.M. , otherwise the day may not change properly. If it is necessary to set the date during the time period, first change the time to any time outside it, set the date and then reset the correct time. 3

3


STOPWATCH FUNCTION

- The measurement of time is indicated by the stopwatch hands that move independently of the center hands.
- The stopwatch can measure up to 60 minutes.

STANDARD MEASUREMENT



ACCUMULATED ELAPSED TIME MEASUREMENT



Restart and stop of the stopwatch can be repeated by pressing the button **A**.

ADJUSTING THE STOPWATCH HAND POSITION


This procedure should be performed when the chronograph second hand does not return to the Zero position after the chronograph has been reset, and including after the battery has been replaced.

1. Pull the crown out to the [2]-**(2nd click)**.
2. Press the button "A" once to set the chronograph second hand to the Zero position.


* The chronograph hands can be advanced rapidly by continuously pressing button "A".

3. Once the chronograph hands been set at Zero position, readjust the normal hour and minute hands to the correct time and return the crown to its normal position.

* Do not return crown to normal position while chronograph second hand returns to 12:00 (ZERO) position. Hand stops on the way when crown is returned to normal position and these positions are recognized as 12:00 (ZERO) position.



STOPWATCH HANDS ZERO POSITIONS



WATER RESISTANCE

The water resistance indicated on your timepiece serves only as a guide. Actual water resistance may vary depending on a number of important factors including temperature, water salinity, and actual use under water.

The water resistance of your timepiece may eventually be compromised over time with general wear and tear and the use of your watch under adverse conditions.

Always remember to employ the screw down crown (if available) to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed.

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch.

The steam may cause condensation inside your watch, which may affect and damage the inner workings of your watch – which would also not be covered by the warranty.