

1988 Mazda RX-7



There is no exterior
photo for this vehicle.


Remote Start, Security, Keyless Entry, Accessories

Item	Wire Color	Polarity	Wire Location
12 Volts	black	+	ignition harness
Second 12 Volts			
Starter	black/red	+	ignition harness
Second Starter			
Ignition	black/white	+	ignition harness
Second Ignition	black/red	+	ignition harness
Third Ignition			
Accessory	blue	+	ignition harness
Second Accessory			
Third Accessory			
Keysense			
Data Bus			
Can Bus High			
Can Bus Low			
Can Bus Sw			
Power Lock			
Power Unlock			
Lock Motor			
Driver Unlock Motor			
Passenger Unlock Motor			
Parking Lights (-)			
Parking Lights (+)	red/black		light switch
Hazards	lt. green	-	theft control unit
Turn Signal (Left)			
Turn Signal (Right)			
Headlight	red/white	-	light switch
AutoLights			
Reverse Light			
Left Front Door Trigger	blue/white	-	theft control unit
Right Front Door Trigger			
Left Rear Door Trigger			
Right Rear Door Trigger			

<i>Remote Start, Security, Keyless Entry, Accessories (Continued)</i>			
Item	Wire Color	Polarity	Wire Location
Dome Supervision			
Trunk/Hatch Pin	green	-	theft control unit
Rear Glass Pin			
Hood Pin	brown/white	-	theft control unit
Trunk/Hatch Release			
Trunk Release Motor			
Fuel Door Release			
Power Sliding Door (Left)			
Power Sliding Door (Right)			
Factory Alarm Arm	green/red	-	theft control unit
Factory Alarm Disarm	lt. green/black	-	theft control unit
Disarm No Unlock			
Trunk Alarm Shunt			
Tachometer	yellow	ac	ign. coil or dianostic
Wait to Start			
Neutral Safety			
Clutch Pedal			
Fuel Pump			
Rear Defroster			
Mirror Defroster			
Left Front Heated Seat			
Right Front Heated Seat			
Speed Sense			
Brake Wire	white/green	+	brake switch
Parking Brake			
Horn Trigger	green/orange	-	steering column
Wipers	blue/red	+	wiper switch
Left Front Window (Up/Down)	grn/blk - red/blk	A	in drivers door
Right Front Window (Up/Down)	grn/wht - red/wht	A	in drivers door or dkp
Left Rear Window (Up/Down)			
Right Rear Window (Up/Down)			
Sun Roof (Open/Close)			
Sun Roof (Limit/Close)			
Memory Seat 1			
Memory Seat 2			
Memory Seat 3			

<i>Audio</i>			
Item	Wire Color	Polarity	Wire Location
Radio 12V			
Radio Ground			
Radio Ignition			
Radio Illumination			
Factory Amp Turn-on			
Power Antenna			
Left Front Speaker (+/-)			
Right Front Speaker (+/-)			
Left Rear Speaker (+/-)			
Right Rear Speaker (+/-)			
Center Channel (+/-)			
Subwoofer (+/-)			
Aux. Audio Input Left (+/-)			
Aux. Audio Input Right (+/-)			
RSE Video (+/-)			
RSE Audio Left (+/-)			
RSE Audio Right (+/-)			
Satellite Radio 12 Volts			
Satellite Radio Ground			
Satellite Radio Ignition			
Satellite Radio Antenna			
Satellite Audio Left (+/-)			
Satellite Audio Right (+/-)			


<i>What Fits</i>			
Item	Size	Depth	Location
Headunit			
Left Front Speaker			
Left Front Tweeter			
Right Front Speaker			
Right Front Tweeter			
Left Rear Speaker			
Left Rear Tweeter			
Right Rear Speaker			
Right Rear Tweeter			
Center Channel			
Subwoofer			
Left Front Headrest			
Right Front Headrest			
Left Rear Headrest			
Right Rear Headrest			
Satellite Radio Tuner			

Wiring Photo and Notes: Hazards




Notes:
Theft control unit is located behind glove box.

Wiring Photo and Notes: Headlight



Notes:
For headlight pop-up give 12v to red/blue at the light switch.



© 2016 Directed. All rights reserved.
DirectWire and its vehicle information are for the sole use of authorized Directed personnel and its participating dealers and distributors. The information contained on these pages may contain confidential and privileged information. Any unauthorized review, use, disclosure or distribution is prohibited.