




Stair Lift Measuring Guide

Measure from the edge of the top landing (A), down to the lower landing (B).



You will provide this measurement in inches in the "Enter Measurement" field on the product page.

If you are unsure of how to measure, please call.