

MAINS TRANSFORMER

MODEL NUMBER: DAT01A

Use this transformer in conjunction with the GreenBrook hardwired doorchimes when you want to have an illuminated doorpush.


- Use with illuminated doorpushes or when converting a doorpush to an illuminated push.

Please read the instructions fully before attempting installation.

This transformer is for use with doorchimes & doorpushes. Disconnect electrical supply before installing. If in doubt, consult a qualified electrician.


INSTALLATION INSTRUCTIONS

1) Remove cover screw A and remove cover B and fix the transformer base C in required position via fixing holes D (see diag.1). It must be located in an accessible position.



2) Connect mains cable to MAINS IN terminals and secure cable to prevent movement.


3) Connect the chime bellwire to the 8V terminals on the transformer and terminals D & C on the doorchime (see Diag. 3). This gives the required 8V output.



If using a wirefree transmitter as well to extend the doorchime system, wire same as (Diag. 4).

Note: This transformer cannot be used with an illuminated doorpush in this application.

Secure the cable to prevent movement.



- 4) Before replacing cover B, check terminals to ensure that no strands of wire are showing. Replace cover B and screw A.
- 5) Switch on power to transformer and check operation.

TECHNICAL SPECIFICATION

Input: 220–240V, 50Hz

Output: 4V, 8V, or 12V, 1 amp

GUARANTEE

Your transformer is guaranteed for 12 months from date of purchase. Please retain till receipt as proof of purchase. This is in addition to your statutory rights.

***PLEASE KEEP THESE
INSTRUCTIONS SAFE
FOR FUTURE REFERENCE***

**GreenBrook's Help Line
01279 772 750**

available during office hours
quoting the model number
DAT01A.

GREENBROOK
ELECTRICAL PLC

West Road,
Harlow,
Essex
CM20 2BG

Tel 01279 772 750
Fax 01279 635 285
Email: sales@greenbrook.co.uk
Web: www.greenbrook.co.uk