



LIFE MADE SMART



IMPORTANT: Read these instructions fully before using this Appliances.

Retain these instructions for future reference.

THE DRINK MAKER FROM CLEARLINE -

Clearline – The drink maker is a compact, easy to use, self-contained carbonation appliance that lets you make your own Club Soda at a fraction of the cost of bottled and canned drinks.

Clearline – The Drink Maker is a Swedish designed, incredibly popular throughout Europe and the United States and enhances the beauty of any kitchen/room/bar with its smart. contemporary looks, while taking up almost no space.

- It is elegant, yet sturdy built.
- It is self-contained, requires no electricity or plumbing.
- No hassles of inserting bottles Sparkling Club Soda straight into the glass.
- It is portable, you can take it with you on picnics, cook-outs, trips or even parties.
- Easy to use & even kids can use it.

It is simply the appliance of the new millennium.

USEFUL TIPS -

- 1. If your drinks foams excessively when filling the glass, pause for a moment and then continue.
- 2. Cooler the water, the better the carbonation.
- 3. If the lid at the top detaches when you open it don't worry, just snap it back into place.
- 4. Never put syrup/mix/juice extract or any other liquid in the machine, use water only.

OPERATING INSTRUCTIONS -

other liquid in the machine, use water only.

- 1. Open the lid and pour in 300ml max. of cold water. When level is just below the bottom pouring hole, that denotes that the carbonating chamber is full. Close the lid. If there is less than 160ml of water, the Drink Maker will not carbonate. Caution DO not put concentrate/syrup/mix/juice extract or any
- 2. Press raised knob on top of the Drink Maker down to carbonate. You can give 2-3 short pressings. When you hear gas escape from the outlet, water is fully carbonated. Any further pressings will simply result in ${\rm CO}_2$ being wasted.
- 3. Hold glass under nozzle at a slight angle so that the carbonated water will hit the side of the glass. Press the lever to fill the glass with fresh sparkling soda. You can add lemon juice or syrup / concentrate to enjoy a great tasting soft drink



Fig -




Fig - 2



Fig - 3

HOW TO CHANGE THE CO, CYLINDER -

The Aluminum $C0_2$ cylinder which is included with your drink maker will make approximately 80-100 glasses of fresh Club Soda. When your cylinder is empty, exchange it for a refill from your authorized Clearline dealer.



Make sure that the dealer exchanges your empty cylinder for a genuine Clearline aluminium cylinder — look for the Company's name and stamp on the cylinder.

- A. Press the white lever behind the outlet nozzle and lift off the top of the machine. The CO₂ cylinder will come out along with the top.
- B. Carefully unscrew cylinder by turning counter clockwise. Screw in new cylinder.
- C. Replace top of machine. The machine is now ready to use.

CLEANING INSTRUCTIONS -

- 1. Clean the machine outside with warm soapy water and then with a dry cloth.
- 2. Rinse the machine inside only with warm water, not with a detergent or a similar product.
- 3. Never use a dish cloth or similar article to clean the inside of the machine.

CLEARLINE CUSTOMER SERVICE

This product carries a Warranty of 12 months from the date of purchase against defects caused by faulty workmanship and materials. The Warranty excludes defects caused by the product not being used in accordance with instructions, misuse, accidental damage and tampering with by unauthorized persons. In the event of any defect arising during Warranty Period, the same should be taken to your nearest dealer or wholesaler. It will then be taken care of as per the discretion of the company's representative. The warranty does not cover damage/defects caused by events beyond control like acts of god, lightning etc.

WARRANTY CARD	
Serial No.	Bill No.
Model No.	The Drink Maker
Customer's Name :	
Address :	
	Dealer's Name & Stamp
Date of Purchase :	



Marketed By:

CLEARLINE APPLIANCES LIMITED 177G, Industrial Area, Phase-I, Chandigarh - 160002

Incase of any complaints please contact: +91 172 4647707 or email us at customercare@clearline.co.in or write to us at the above mentioned address

www.clearline.co.in