



LIFE MADE SMART



# Powerful 4 RODS with 2000W output

IMPORTANT: Please read these instructions fully before using the appliance.

Kindly retain these instructions for future reference.

#### **SPECIFICATIONS**

Specifications – 230V  $\sim$  50Hz, 2000 Watts


### SAFETY INSTRUCTIONS

- 1. In order to avoid overheating, do not cover the heater.
- Do not turn on the heater if the casing shows visible damage (cracks/breaks), if the power cord is faulty or if any invisible defect is suspected (for instance, after a fall).
- Only connect the heater if the voltage indicated on the rating label corresponds with the mains voltage at your place.
- 4. Heater surfaces that radiate heat can become hotter than 60°C.
- 5. When in use, the power cord must not lie on the heater.
- Be careful and do not use the heater in the immediate surroundings of a bath, a shower or swimming pool.
- 7. The heater must be placed in such a way that combustible objects cannot catch fire.
- 8. The heater must not be located immediately below a socket outlet.
- The heater must be positioned away from towels, curtains and such likes, as there is danger of overheating when it is covered.
- 10. For maintenance and after use, the heater must always be turned off, the plug must be pulled out and the heater must be allowed to cool down.
- The heater must not be stored outdoors.
- 12. The heater may only be cleaned with a dry cloth or with a slightly moist cloth. The electric parts (switch, plug, heating element etc.) must not get in touch with water.
- 13 . The heater has hot and/or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- 14. Do not use this heater with a programmer, timer or any other device that switches the heater on automatically since a risk of fire exists, if heater is covered or positioned incorrectly.
- 15. If the supply cord is damaged, it must be replaced by the manufacturer, service agent or similarly qualified persons in order to avoid a hazard.
- 16. The plug must be removed from power outlet before cleaning the reflector.
- 17. Front grill must be in place when heater is in use to prevent direct access to the heating element.
- 18. Front grill becomes hot, keep out of reach of children and infirm persons.
- 19. Do not use the heater to dry clothes.
- 20. Keep away from steam coming from the steam outlet. It can cause burn injuries.

#### KNOW YOUR HEATER

- 1. Front Grill
- 2. Power Switches (1 and 2)
- 3. Switch for Humidifier
- 4. Heating Elements

- 5. Water Inlet cum Steam Outlet
- 6. Water level indicator
- 7. Tip Over Switch



## INSTRUCTIONS TO USE

The heater has 2 heat settings – 1000W and 2000W.

The switch marked 1 switches on 2 rods of 500W each and switch marked 2 switches on the remaining 2 rods of 500 Watts each.

The Switch which has steam marked under it will turn on the humidifier which helps in keeping the environment humid.

To fill the humidifier with water, pour water into the water inlet till the water indicator reaches max level.

#### CLEARLINE CUSTOMER SERVICE

This product carries a warranty of 12 months from the date of purchase against defects caused by faulty workmanship and materials. The warranty excludes defects caused by the product not being used in accordance with instructions, mis-use, accidental damage and tampering with by un-authorised persons. In the event of any defect arising during warranty period, the same should be taken to your nearest dealer or wholesaler. It will then be taken care of as per the discretion of the company's representative. The warranty does not cover damage/defects caused by the events beyond control like acts of god, lightning, abnormal power supply, voltage fluctuations.

WARRANTY CARD	
Serial No.	Bill No.
Model No.	Quartz Tube Heater
Customer's Name :	
Address :	
	Dodor's Name 9 Stamp
	Dealer's Name & Stamp
Date of Purchase :	



Marketed By:

#### CLEARLINE APPLIANCES LIMITED

177G, Industrial Area, Phase-I, Chandigarh - 160002

Incase of any complaints please contact: +91 172 4647707 or email us at customercare@clearline.co.in or write to us at the above mentioned address