

Instructions for programming remote

1. Turn on toggle switch;
2. Press spin buttons “top” & “back” at same times on machine’s panel;
3. Press buttons “height ▲” & “spin ▲” at same times;
4. Press “power” button on remote;
5. Press “power” button on machine’s panel.