

Micro USB Port

Bright RGB LED

Charging Indicator

Single Button

## •Light Functions

- 1. Turn Light ON:** Click Button to turn Light ON.
- 2. Turn Light OFF:** Click and Hold Button Down for .5 second until Light turns OFF, then Release.
- 3. Change Color Mode:** Click Button to cycle Color Modes #1-#12 then OFF.
- 4. Change Flash Pattern:** From any Color Mode, Click and Hold Button Down for 1 second until Light flashes Orange, then Release. Click Button to cycle Flash Patterns #1-#3 in a Loop. To select a Flash Pattern, Click and Hold Button Down for 1 second, then Release to return to Color Modes.
- 5. Smart Button Lock:** If Light is ON and there is no Button activity for 3 seconds, Smart Button Lock will Activate. To Deactivate, Click Button more than 1 time in a 3 second period.
- 6. Activate Factory Reset:** While Light is OFF, Click and Hold Button Down for 5 seconds until Light flashes White, then Release.

	Color Mode #1	Color Mode #2	Color Mode #3	Color Mode #4	Color Mode #5	Color Mode #6	Color Mode #7	Color Mode #8	Color Mode #9	Color Mode #10	Color Mode #11	Color Mode #12
Flash Pattern #1	 Red Strobe	 Yellow Strobe	 Green Strobe	 Aqua Strobe	 Blue Strobe	 Pink Strobe	 White Strobe	 Fire Strobe	 Morph Strobe	 Rainbow Strobe	 TriColor Strobe	COLOR MODES #1-#11 Demo Pink
Flash Pattern #2	 Red Ribbon	 Yellow Ribbon	 Green Ribbon	 Aqua Ribbon	 Blue Ribbon	 Pink Ribbon	 White Ribbon	 Fire Ribbon	 Morph Ribbon	 Rainbow Ribbon	 TriColor Ribbon	COLOR MODES #1-#7 Demo Green
Flash Pattern #3	 Red Hybrid	 Yellow Hybrid	 Green Hybrid	 Aqua Hybrid	 Blue Hybrid	 Pink Hybrid	 White Hybrid	 Fire Comet	 Morph Candy	 Rainbow Dash Dot	 TriColor Fuzion	COLOR MODES #8-#11 Demo Blue



# UltraKnob Pro

LED Flow Handle

# ORBPOI

LED Contact Poi

## •Setup



## •Charging




## •Setup

1. Place Metal Ring on Rope and Melt End Flat.
2. Trap Rope Inside Shell and Close with O Rings.

## •Charging

1. Charge Battery with Micro USB Cable.
2. Red LED will turn OFF after Charging.

## •Parts



UltraGrip Pro



Knob Shell



Orb Shell



Orb Case