


To view assembling video



Instruction Manual

Jungle Gym Ultimate




Note

- We suggest 2 people to take charge of the assembly.
- Assembly takes 30 45 minutes.
- Involve your child in the assembly as this will give them a sense of belonging and will warm the child towards the Jungle Gym.
- Unwrap the Jungle Gym parts and place it as shown in the image for convenient assembly.
- Mildly secure the screws and knobs.
- Tighten after you complete the assembly. Don't over tighten

Hold the top supporter 1 (with the logo facing towards you), as shown in the picture.

Place the rope ladder on the left and step ladder on the right of the top supporter 1.





Step - 2

Always use knobs on one side of the gym and screws on the other. Since knobs enable you to fold the gym it is better to keep them all on one side (either left or right).

After screwing the knobs and screws the ladders will form a V, this assembly can stand by itself.

Step - 3

Take the top supporter – 2 and place it as shown in the image. The logo side of the Top supporter 2 should face outwards.



Position the legs of the gym against the Top-Supporter 2 as shown in the picture. Ensure the grove in the leg is facing inwards. Secure the legs.





Step - 5

Place one short support rod against the middle of the legs, as shown in the image and secure it.

Step - 6

Place one long support rod at the bottom of the legs, as shown in the image and secure it.



Place one white support rod, between the legs at the bottom, in the groves provided as shown in the image.

Similarly, place the other white support rod on the opposite side and secure it.





Step - 8

Now move to the ladder side of the gym. Place the other short support rod in the middle. Secure only one end.

Now slide the baby ladder into the rod as shown in the picture and secure the other end of the rod.



Place the slider as shown in the image.



Position the swing at the desired height and secure the knots on all four points as shown in the image.





Step - 11

Tie the gymnastic rings on top supporter-1.



Place the wooden plank as shown in the image. Now gently tighten all the screws. DO NOT over tighten the

screws



Your Jungle Gym Ultimate is ready for the little one to explore.



We can guide you over video call in case you need assistance

www.arirotoys.com 89399 92452/ help@arirotoys.com