


# DAIWA SPINNING REEL

## BGMQ14000-H

\*Please order by parts number, not key number.



### Key No Part No Description

1	M13-0901	DRAG KNOB
2	170-4101	DRAG RING
3	J97-9901	DRAG RATCHET
4	J57-7203	DRAG WASHER
5	M12-6601	DRAG DISK WASHER
6	M12-6701	DRAG LIP WASHER
7	B35-8607	SPOOL BALL BEARING
8	M12-0601	SPOOL ASSY
9	F05-0104	SPOOL WASHER(A)
10	F05-0002	SPOOL WASHER(B)
11	H30-9501	CLICK HOLDER
12	B74-7701	CLICK LEAF SPRING
13	F04-9901	SPOOL WASHER( C )
14	G27-0801	ROTOR COVER SCREW
15	J99-2601	ROTOR COVER
16	J89-8101	ROTOR NUT PACKING
17	J99-6301	ROTOR NUT
18	H50-1001	ROTOR NUT O RING
19	G39-2202	ROTOR NUT PLATE
20	J32-1604	ROTOR
21	H50-3401	ROTOR BRAKES SPRING
22	G68-5401	ROTOR BRAKES SPRING WASHER
23	H50-3301	ROTOR BRAKES SHAFT
24	J32-2001	ARM LEVER SPRING COLLAR
25	J32-1901	ARM LEVER SPRING
26	J32-1801	ARM LEVER SHAFT WASHER
27	J32-1701	ARM LEVER SHAFT
28	H94-5501	ARM LEVER SCREW COLLAR
29	J30-9703	ARM LEVER
30	G45-5601	ARM LEVER SCREW
31	J32-2103	ARM LEVER COVER
32	G27-0801	ARM LEVER COVER SCREW
33	F60-8901	ROLLER SCREW
34	J31-0401	ROLLER COLLAR(A)
35	J41-6001	ROLLER COLLAR(B)
36	H24-6103	LINE ROLLER
37	J32-3301	BAIL ASSY
38	J99-6101	SEALED CAP COLLAR
39	G16-2301	SEALED CAP PACKING
40	J99-3201	SEALED CAP
41	J96-1401	SEALED CAP PLATE

### Key No Part No Description

42	J96-1501	SEALED CAP O RING
43	J30-9101	ONE WAY CLUTCH
44	J30-9002	CLUTCH RING
45	J00-1602	BEARING PLATE SCREW
46	J30-8401	BEARING PLATE
47	G42-6301	PINION BALL BEARING ( A )
48	G61-3404	PINION BEARING ( A ) WASHER01mm
49	E26-2701	RATCHET
50	G61-3404	PINION BEARING ( B ) WASHER
51	M05-7102	PINION BEARING ( A ) COLLAR
52	Z02-5984	PINION DRIVE GEAR UNIT
53	G57-8501	PINON BEARING SP WASHER
54	G52-2706	PINON BALL BEARING ( B )
55	J32-0901	PINION BEARING ( B ) COLLAR
56	H62-9701	SEALED CAP RING
57	M12-0501	BODY ASSY
58	J99-2701	MAIN SHAFT ASSY
59	J32-0801	OSHRATING POST
60	J99-3001	REAR CAP PACKING
61	J99-3101	REAR CAP
62	M05-6601	REAR CAP SCREW(A)
63	M05-6602	REAR CAP SCREW(B)
64	J32-0401	OSCILATE GEAR
65	G46-7105	OSCILATE BALL BEARING
66	H27-2202	OSCILATE GEAR SCREW
67	H24-3301	STOPPER CAM
68	M09-3801	STOPPER
69	351-6401	STOPPER SCREW
70	J30-8601	STOPPER SPRING
71	J32-1201	DRIVE GEAR O RING
72	371-2824	DRIVE WASHER
73	G52-2802	DRIVE BALL BEARING ( A )
74	J89-4101	BODY COVER PACKING
75	J99-2901	BODY COVER
76	J43-2001	HANDLE PACKING
77	M06-4001	HANDLE ASSY
78	G52-2802	DRIVE BALL BEARING ( B )
79	H04-7201	DRIVE BEARING RING
80	J04-2501	HANDLE CAP O RING
81	J39-4903	HANDLE CAP