


DAIWA

SPINNING REEL

BGMQ2500D-H

*Please order by parts number, not key number.



Key No	Part No	Description	Key No	Part No	Description
1	M08-4601	DRAG KNOB	44	M03-7001	SEALED PACKING COLLAR
2	J54-7101	DRAG RING	45	M03-7302	SEALED CAP
3	M03-7701	DRAG RATCHET	46	M03-7201	SEALED CAP O RING
4	J54-7001	DRAG DISK WASHER	47	J63-9902	ONE WAY CLUTCH WASHER
5	M20-6501	ATD DRAG WASHER ((25BGMQ 3)	48	J38-8402	ONE WAY CLUTCH
6	J54-6902	DRAG LIP WASHER	49	M08-4102	CLUTCH RING
7	J55-8101	LINE STOPPER PLATE	50	J53-6202	CLUTCH RING COLLAR
8	J55-8001	LINE STOPPER	51	J00-0901	BEARING PLATE SCREW
9	J31-4801	LINE STOPPER SPRING	52	J77-8201	BEARING PLATE
10	M08-4401	SPOOL ASSY	53	G46-7302	PINION BALL BEARING (A)
11	M03-7401	SPOOL WASHER(A)	54	375-8502	PINION BEARING (A) WASHER01mm
12	G46-9005	SPOOL BALL BEARING	55	Z02-5766	PINION DRIVE GEAR UNIT
13	B41-1706	SPOOL WASHER(B)	56	H93-1701	PINION SPRING WASHER
14	E39-8003	SPOOL WASHER(C 03mm)	57	G46-6202	PINON BALL BEARING (B)
15	E46-7101	SPOOL WASHER(D)	58	G46-6103	PINION BEARING (B) WASHER
16	M02-1401	CLICK HOLDER	59	J38-7701	PINION BEARING (B) COLLAR
17	H41-6101	CLICK LEAF SPRING	60	M08-2801	BODY ASSY
18	J70-3101	SPOOL WASHER(D)	61	J02-2601	BAIL KICK COLLAR
19	H98-6901	ROTOR NUT PACKING	62	G94-0408	BAIL KICK COLLAR SCREW(A)
20	M18-1301	ROTOR NUT	63	H53-1510	BAIL KICK COLLAR SCREW(B)
21	J80-8500	ROTOR NUT COLLAR	64	M08-3201	MAIN SHAFT ASSY
22	H02-2701	ROTOR NUT SCREW	65	H59-6301	OSHRATING POST
23	J54-5314	ROTOR	66	M03-9401	OSHRATING POST COLLAR
24	H41-3601	KICK LEVER SPRING	67	M08-4001	REAR CAP PACKING
25	J54-5401	KICK LEVER ASSY	68	M08-5101	REAR CAP
26	H41-7701	KICK LEVER SCREW	69	M03-6601	REAR CAP SCREW
27	J54-5601	ARM LEVER SHAFT	70	H59-5701	OSCILATE GEAR WASHER
28	H57-6101	ARM LEVER SPRING COLLAR	71	H62-9101	OSCILATE GEAR
29	J64-2801	ARM LEVER SPRING	72	H77-0601	OSCILATE GEAR O RING
30	H41-4301	ARM LEVER SPRING HOLDER	73	H12-9201	OSCILATE BEARING WASHER01mm
31	J54-5701	ARM LEVER COVER	74	G46-9005	OSCILATE GEAR BALL BEARING
32	G27-0801	ARM LEVER COVER SCREW	75	G94-0402	OSCILATE SCREW
33	H72-8927	ARM LEVER	76	G67-0501	DRIVE O RING
34	H96-2401	ARM LEVER COLLAR	77	375-8502	DRIVE BEARING WASHER01mm
35	G20-5001	ARM LEVER SCREW	78	G46-7302	DRIVE BALL BEARING (A)
36	G19-5602	ROLLER SCREW	79	J55-3001	BODY COVER PACKING
37	J56-6101	ROLLER COLLAR(A)	80	M08-3801	BODY COVER
38	M17-8101	ROLLER COLLAR(B)	81	J13-0201	HANDLE PACKING
39	J08-9902	LINE ROLLER	82	M08-4801	HANDLE ASSY
40	M17-8001	ROLLER COLLAR(C)	83	G52-2706	DRIVE BALL BEARING (B)
41	M08-4301	BAIL ASSY	84	G47-2401	DRIVE BEARING RING
42	G20-5001	BAIL HOLDER SCREW	85	G16-2401	HANDLE CAP O RING
43	M03-7101	SEALED PACKING	86	J41-8102	HANDLE CAP