


# SPINNING REEL

LEGLT2500D\_LEGLT2500D-XH\_LEGLT3000D-C\_LEGLT4000D-C\_LEGLT5000D-C\_LEGLT6000D  
 \*Please order by parts number, not key number.



Key No	Part No	Description	Part No	Part No	Part No	Part No	Part No
1	Q34-6201	DRAG KNOB	Q34-6201	Q34-6201	Q35-2901	Q35-2901	Q36-4201
2	Q34-6101	DRAG RING	Q34-6101	Q34-6101	Q34-6101	Q34-6101	170-4101
3	Q62-1901	DRAG DISC WASHER	Q62-1901	Q62-1901	Q62-1901	Q62-1901	J57-7501
4	J54-6801	DRAG WASHER	J54-6801	J54-6801	J54-6801	J54-6801	J57-7201
5	Q34-6001	DRAG LIP WASHER	Q34-6001	Q34-6001	Q34-6001	Q34-6001	Q37-7601
2~6	Q68-9601	SPOOL ASSY ( 2-6 )	Q68-9901	Q69-0401	Q69-0901	Q69-1401	Q69-1901
7	E39-8003	SPOOL WASHER ( A )	E39-8003	E39-8003	E39-8003	E39-8003	F05-0104
8	Q34-8502	SPOOL WASHER ( B )	Q34-8502	Q34-8502	Q34-8502	Q34-8502	Q36-3801
9	H41-6101	CLICK LEAF SPRING	H41-6101	H41-6101	H41-6101	H41-6101	H41-6101
10	M02-1401	CLICK HOLDER	M02-1401	M02-1401	M02-1401	M02-1401	M02-1501
11	Q34-4001	CLICK HOLDER WASHER	Q34-4001	Q34-4001	Q34-4001	Q34-4001	Q37-7501
12	Q12-2401	ROTOR NUT	Q12-2401	Q12-2401	Q12-2401	Q12-2401	Q13-5201
13	H02-2701	ROTOR NUT SCREW	H02-2701	H02-2701	H02-2701	H02-2701	H02-2701
14	Q34-3019	ROTOR	Q34-3019	Q12-0529	Q35-1814	Q12-9223	Q13-4525
15	H41-3601	KICK LEVER SPRING	H41-3601	H41-3601	H41-3601	H41-3601	H41-3601
16	Q34-3101	KICK LEVER	Q34-3101	Q12-0701	Q35-1901	Q12-9301	Q13-4601
17	H41-7701	KICK LEVER SCREW	H41-7701	H41-7701	H41-7701	H41-7701	H41-7701
18	Q34-3301	ARMLEVER SHAFT	Q34-3301	Q12-1201	Q12-9501	Q12-9501	Q13-4801
19	H57-6101	ARMLEVER SHAFT PLATE	H57-6101	H57-6101	H57-6101	H57-6101	H57-6101
20	J64-2801	ARMLEVER SPRING	J64-2801	H54-5701	H41-4201	H41-4201	H64-0701
21	Q12-1501	ARMLEVER SPRING HOLDER	Q12-1501	Q12-1501	Q12-1501	Q12-1501	Q12-1501
22	Q34-3501	ARMLEVER SPRING COVER	Q34-3501	Q12-1801	Q35-2101	Q12-9601	Q13-4901
23	Q34-2901	ARMLEVER SPRING COVER SCREW	Q34-2901	Q34-2901	Q34-2901	Q34-2901	Q34-2901
24	Q12-1622	ARMLEVER	Q12-1622	Q12-1622	Q12-1622	Q12-1622	Q12-1622
25	Q12-1701	ARMLEVER SCREW COLLER	Q12-1701	Q12-1701	Q12-1701	Q12-1701	Q12-1701
26	Q34-3401	ARMLEVER SCREW	Q34-3401	Q34-3401	Q34-3401	Q34-3401	Q34-3401
27	G19-5602	ROLLER SCREW	G19-5602	G19-5602	G19-5602	G19-5602	G19-5602
28	G19-5501	ROLLER COLLAR ( A )	G19-5501	G19-5501	G19-5501	G19-5501	G19-5501
29	G22-0701	ROLLER COLLAR ( B )	G22-0701	G22-0701	G22-0701	G22-0701	G22-0701
30	J08-9902	LINE ROLLER	J08-9902	J08-9902	J08-9902	J08-9902	J08-9902
31	Q20-3401	ROLLER COLLAR ( C )	Q20-3401	Q20-3401	Q20-3401	Q20-3401	Q20-3401
32	Q34-3601	BAIL ASSY	Q34-3601	Q12-1901	Q35-2201	Q12-9701	Q13-5001
33	G83-7101	SEALED PLATE SCREW	G83-7101	G83-7101	G83-7101	G83-7101	G83-7101
34	Q13-9401	SEALED PLATE	Q13-9401	Q12-0101	Q12-9001	Q12-9001	Q13-4301
35	Q30-8301	ONEWAY CLUTCH	Q30-8301	J38-8401	J38-8401	J38-8401	J30-9101
36	J00-1401	CLUTCH RING	J00-1401	J00-1403	J00-1403	J00-1403	J69-0501
37	Q12-6201	PINION BEARING PLATE SCREW	Q12-6201	Q12-6201	Q12-6201	Q12-6201	Q19-5701
38	Q19-5601	PINION BEARING PLATE	Q19-5601	Q19-5601	Q19-5601	Q19-5601	Q20-5901
39	G46-7302	PINION BALL BEARING(A)	G46-7302	G46-7302	G53-5104	G53-5104	G35-4801
40	375-8502	PINION BALL BEARING(A) WASHER	375-8502	375-8502	375-8502	375-8502	371-2824
41	Q34-1701	PINION GEAR	Q36-0301	Q34-1701	Q35-1201	Q35-1201	Q40-5001
42	H93-1701	PINION BALL BEARING(B) SPRING WASHER	H93-1701	H93-1701	H93-1701	H93-1701	G57-2501
43	H95-9601	PINION BALL BEARING(B)	H95-9601	H95-9601	G46-6202	G46-6202	G46-7106
44	---	PINION BALL BEARING(B) COLLAR	---	---	---	---	---
45	Q68-9401	BODY	Q68-9401	Q69-0201	Q69-0701	Q69-0701	Q69-1701
46	Q34-1501	MAIN SHAFT	Q34-1501	Q45-9401	Q35-1001	Q35-1001	Q36-2601
47	Q12-6301	OSCILLATING POST( A )	Q12-6301	Q12-6301	Q12-6302	Q12-6302	Q12-6303
48	Q11-9101	OSCILLATING POST( B )	Q11-9101	Q11-9101	Q11-9102	Q11-9102	Q11-9103
49	Q11-8101	STOPPER CAM	Q11-8101	Q11-8101	Q11-8101	Q11-8101	Q13-3401
50	H69-7801	STOPPER LEVER SPRING	H69-7801	H69-7801	H69-7801	H69-7801	H69-7801
51	Q11-8001	STOPPER LEVER	Q11-8001	Q11-8001	Q11-8001	Q11-8001	Q11-8001
52	Q62-6401	REAR COVER	Q62-6401	Q62-6401	Q67-4801	Q67-4801	Q67-5901
53	Q34-2901	REAR COVER SCREW	Q34-2901	Q34-2901	Q34-2901	Q34-2901	Q34-2901
54	H59-5701	OSCILLATING GEAR WASHER	H59-5701	H59-5701	H59-5701	H59-5701	G64-4201
55	Q13-9001	OSCILLATING GEAR	Q13-9001	Q11-8401	Q35-0901	Q35-0901	Q13-3501
56	H77-0601	OSCILLATING GEAR O-RING	H77-0601	H77-0601	G46-6001	G46-6001	B85-3101
57	H12-9201	OSCILLATING GEAR BEARING WASHER	H12-9201	H12-9201	H12-9201	H12-9201	G52-2103
58	G46-9005	OSCILLATING GEAR BALL BEARING	G46-9005	G46-9005	G46-9005	G46-9005	G46-7105
59	Q12-6101	OSCILLATING GEAR SCREW	Q12-6101	Q12-6101	Q12-6101	Q12-6101	H46-3401
60	G67-0501	DRIVE GEAR O-RING	G67-0501	G67-0501	G67-0501	G67-0501	G64-5301
61	Q34-1901	DRIVE GEAR	Q36-0501	Q34-1901	Q35-1401	Q35-1401	Q40-5101
62	375-8502	DRIVE WASHER	375-8502	375-8502	375-8502	375-8502	373-7808
63	G46-7302	DRIVE BALL BEARING(A)	G46-7302	G46-7302	G46-7302	G46-7302	B86-1705
64	Q68-9501	BODY COVER	Q68-9501	Q68-9501	Q69-0801	Q69-0801	Q69-1801
65	Q34-2701	BODY COVER SCREW ( A )	Q34-2701	Q34-2701	Q34-2701	Q34-2701	Q34-2701
66	Q34-2601	BODY COVER SCREW ( B )	Q34-2601	Q34-2601	Q34-2601	Q34-2601	Q34-2601
67	Q69-0301	HANDLE ASSY	Q69-0301	Q69-0301	Q69-2801	Q69-2801	Q69-2901
68	G52-2706	DRIVE BALL BEARING(B)	G52-2706	G52-2706	G52-2706	G52-2706	G52-3405
69	G47-2401	DRIVE BEARING RETAINER	G47-2401	G47-2401	G47-2401	G47-2401	G52-5101
70	F72-1001	HANDLE SCREW COLLAR	F72-1001	F72-1001	F72-1001	F72-1001	F72-1202
71	160-8401	HANDLE SCREW WASHER	160-8401	160-8401	160-8401	160-8401	160-8401
72	Q13-2401	HANDLE SCREW	Q13-2401	Q13-2401	Q13-2401	Q13-2401	Q13-6101