



Key No	Part No	Description	Key No	Part No	Description
1	460-5620	Set plate screw	52	4605320	Long screw
2	510-4450	Set plate spring	53	55A1720	Frame plate
3	550-1700	Brake adjusting knob	54	4901102	Line guide
4	510-5341	Brake click spring	55	4002540	Line guide pawl
5	200-0530	Brake dial retainer(A)	56	5403980	Washer
6	540-5380	Washer	57	3800780	Line pawl cap
7	23A-2590	Right side plate	58	2700870	Level wind guard
8	410-2720	Brake dial retainer(B)	59	4702430	Worm shaft
9	230-2600	Set plate	60	1501050	Bushing
10	460-3220	Screw	61	2402300	Worm shaft gear
11	240-2290	Magnet holder	62	2000530	Geart retainer
12	430-1070	Magnet holder ret. Ring	63	40A3380	Pillar
13	540-8120	Washer	64	2001160	E-Clip
14	540-8110	Spacer(A)	65	1402180	Ball bearing
15	140-3310	Ball bearing	66	5407250	Washer
16	430-0440	Bearing retainer	67	2000580	Drive gear shart retainer
17~20	702-1770	Spool assembly	68	4102740	Plate
21	410-2680	Spacer (B)	69	4605290	Screw
22	090-0290	Clutch lever	70	4605370	Screw
23	410-2670	Spacer (C)	71	5406600	Washer
24	702-1820	Frame	72	2402260	Oscillation gear
25	400-2570	Pin	73	4702500	Drive shaft
26	510-5310	Spring	74	5300860	Anti-reverse pawl
27	400-2720	Pin	75	2403030	Anti-reverse ratchet
28	170-1380	Clutch cam	76	5406670	Spacer (F)
29	410-2730	Plate	77	2501570	Drive gear
30	510-5330	Spring	78	5407100	Washer
31	460-1290	Screw	79	5408060	Key washer
32	400-3310	Kick lever pin	80	5409890	Drag washer
33	330-2951	Kick lever	81	5408100	Key washer
34	510-5320	Kick lever spring	82	5408090	Drag washer
35	210-2410	bushing	83	5408070	Top washer
36	200-0570	E-Clip	84	1502270	Gear shaft collar
37	410-2751	Yoke	85	1402000	Roller clutch
38	510-6040	Yoke spring	86	1402130	Ball bearing
39	260-2760	Pinion gear	87	5406250	Spacing washer
40	702-1830	Left side plate	88	5105370	Plate
41	460-5790	Screw	89	5406391	Drag spring washer
42	460-4870	Screw	90	5409021	Washer
43	460-7430	Screw	91	3803220	NUT
44	430-1061	Bearing retainer	92	5106130	Spring
45	150-2060	Bushing	93	32A1330	Star drag
46	430-1000	O-Ring	94	5409301	Washer
47	540-6460	Spacer	95	5409271	Washer
48	540-5980	Spacer	96	7021780	handle assembly
49	38A-1990	Cast control cap	97	3801930	Handle nut
50	200-0580	Worm shaft retainer	98	41A2500	Handle nut plate
51	150-2260	Bushing	99	4604260	Screw