


SALIGA

CONVENTIONAL REEL

SAGLD15_20-2SPD

*Please order by parts number, not key number.



Key No	Part No	Description
1	E76-6501	FRAME
2	E72-5103	CLICK BUTTON
3	E72-5301	CLICK COLLAR
4	E72-5201	CLICK PLATE
5	E61-7401	CLICK BUTTON WASHER
6	E74-4501	CLICK PAWL
7	320-1402	CLICK PAWL RETAINER
8	E74-4701	CLICK SPRING
9	E67-0011	FRAME PLATE
10	E73-0001	FRAME PLATE SCREW
11	G21-1701	FRAME PIN
12	E76-6801	SPOOL
13	E76-6901	DRAG WASHER
14	E76-7001	MAIN SHAFT
15	E57-8301	BEARING WASHER
16	E64-1201	DRAG SPRING WASHER
17	G53-6001	SPOOL BALL BEARING (A)
18	E76-7201	DRAG CLICK CAP
19	B35-2701	BRAKE COLLAR
20	E64-3802	DRAG CLICK CAP SCREW
21	G49-8511	SPOOL BALL BEARING (B)
22	E66-5501	TENTION SPRING
23	G53-6001	SPOOL BALL BEARING (C)
24	E66-5602	DRAG PLATE
25	E66-6001	DRAG WASHER COVER
26	E66-8901	DRAG WASHER COVER SCREW
27	E66-5801	DRAG WASHER COVER PACKING
28	E64-1601	MAIN SHAFT PIN
29	E77-0001	RIGHT SIDE PLATE
30	E76-7701	DRIVE SHAFT
31	E64-1901	DRIVE SHAFT PIN (A)
32	E66-6301	DRIVE SHAFT SPRING (A)
33	E66-6401	DRIVE SHAFT SCREW
34	E66-6501	DRIVE SHAFT PIN (B)
35	E66-6701	DRIVE SHAFT SPRING (B)
36	E66-6601	DRIVE SHAFT COLLAR
37	G47-2501	DRIVE SHAFT BALL BEARING
38	E66-9001	DRIVE SHAFT BEARING WASHER
39	E64-2201	DRIVE GEAR COLLAR (A)
40	E64-2301	DRIVE GEAR (A)
41	E64-2401	DRIVE GEAR COLLAR (B)
42	E64-2501	DRIVE GEAR (B)
43	E65-6801	DRIVE GEAR COLLAR (C)
44	E64-2601	DRIVE GEAR COLLAR (D)
45	E64-2701	DRIVE SHAFT NUT
46	E64-4301	DRAG LEVER STOPPER COLLAR
47	E59-1601	DRAG LEVER STOPPER SCREW

Key No	Part No	Description
48	E76-7401	CLICK GEAR
49	E17-5802	PINION BALL BEARING
50	E64-2801	PINION GEAR (A)
51	E66-6801	PINION GEAR (B)
52	E76-7801	ANTI REVERSE RATCHET
53	E76-7901	ANTI REVERSE PAWL PIN
54	E64-3501	ANTI REVERSE PAWL
55	E64-3701	ANTI REVERSE PAWL RETAINER
56	E64-3801	ANTI REVERSE PAWL SCREW
57	E76-8001	DRAG LEVER WASHER
58	E73-9102	SIDE PLATE SCREW
59	E76-8101	DRAG LEVER
60	E75-9401	CLICK PAWL
61	M16-3301	CLICK PAWL SPRING
62	E72-8201	CLICK PAWL COLLAR
63	E76-8401	PRESET CAM (A)
64	E76-8501	BUSHING
65	E76-8701	BUSHING RETAINER
66	E76-8901	PRESET CAM (B)
67	E76-8801	PRESET CAM (B) O RING
68	E76-9001	CLICK LEAF SPRING
69	E76-9201	DRAG KNOB SPRING
70	E76-9101	PRESET DRAG KNOB
71	G52-2801	HANDLE BALL BEARING
72	E66-8101	HANDLE CAP (A)
73	E76-9301	HANDLE ASSEMBLY
74	E76-9601	HANDLE SCREW
75	E66-8601	HANDLE PLATE
76	350-8912	HANDLE PLATE SCREW
77	E66-9201	HANDLE LEVER PLATE
78	E64-7701	HANDLE LEVER PLATE SPRING
79	E64-7901	HANDLE LEVER
80	H56-2103	HANDLE CAP (B)
81	G04-0815	HANDLE CAP SCREW

SAGLD20-2SPD Special Parts

Key No	Part No	Description
1	E77-4601	FRAME
9	E67-0013	FRAME PLATE
12	E77-4701	SPOOL
14	E77-4801	MAIN SHAFT
29	E77-0003	RIGHT SIDE PLATE
82	E77-4101	CLAMP BOLT
83	E61-4001	CLAMP NUT (A)
84	H60-0603	ROD CLAMP
85	H60-0801	CLAMP NUT (B)