


SAGLD55_60-2SPD

CONVENTIONAL REEL

*Please order by parts number, not key number.



Key No	Part No	Description
1	E77-2301	FRAME
2	E74-3701	CLICK BUTTON
3	E72-5301	CLICK COLLAR
4	E72-5201	CLICK PLATE
5	E67-9401	CLICK BUTTON WASHER
6	E67-9301	CLICK PAWL
7	320-1402	CLICK PAWL RETAINER
8	E74-3601	CLICK SPRING
9	E67-9609	FRAME PLATE
10	F50-5703	FRAME PLATE SCREW
11	E67-7101	HARNES LUG(L)
12	E68-5901	HARNES LUG SCREW
13	E67-7201	HARNES LUG(R)
14	E67-9701	PIN
15	E77-1501	SPOOL
16	E77-1601	DRAG WASHER
17	E77-2601	MAIN SHAFT
18	373-7816	BEARING WASHER
19	E68-0201	DRAG SPRING WASHER
20	E68-0301	BALL BEARING(A)
21	E68-0801	DRAG CLICK CAP
22	B35-2701	BRAKE COLLAR
23	G29-7001	DRAG CLICK CAP SCREW
24	H42-8701	BALL BEARING(B)
25	E68-0601	SPRING(A)
27	E68-1001	DRAG METAL
28	E68-6101	DRAG METAL SCREW
29	E68-1102	DRAG PLATE
30	E68-1201	DRAG WASHER COVER
31	E66-8901	DRAG WASHER COVER SCREW
32	E68-1301	PACKING
33	E68-1401	MAIN SHAFT PIN
34	E77-2801	RIGHT SIDE PLATE
35	E74-5501	DRIVE SHAFT
36	E68-2001	DRIVE SHAFT PIN(A)
37	E68-2101	DRIVE SHAFT SPRING(A)
38	E68-2201	DRIVE SHAFT SCREW
39	E66-6501	DRIVE SHAFT PIN(B)
40	E68-2401	DRIVE SHAFT SPRING(B)
41	E77-4301	DRIVE SHAFT COLLAR
42	F64-1602	BALL BEARING(D)
43	E68-2601	DRIVE GEAR COLLAR(A)
44	E68-2701	DRIVE GEAR COLLAR(B)
45	E68-2801	DRIVE GEAR(A)
46	E68-2901	DRIVE GEAR COLLAR(C)
47	E68-3001	DRIVE GEAR(B)
48	E68-2501	DRIVE GEAR COLLAR (D)
49	E68-3101	DRIVE SHAFT NUT
50	E75-9601	PUSH BUTTON
51	E68-6201	PUSH BUTTON SPRING

Key No	Part No	Description
52	B33-9801	PUSH BUTTON RETAINER
53	E64-4301	DRAG LEVER STOPPER COLLAR
54	E59-1601	DRAG LEVER STOPPER SCREW
55	E75-8201	CLICK GEAR
56	E68-5601	BALL BEARING(E)
57	E68-3201	PINION GEAR(A)
58	E68-3301	PINION GEAR(B)
59	E68-3401	ANTI REVERSE RATCHET
60	E68-3801	ANTI REVERSE PAWL PIN
61	E68-3501	ANTI REVERSE PAWL
62	E64-3701	ANTI REVERSE PAWL RETAINER
63	E64-3802	ANTI REVERSE PAWL SCREW
64	E73-2101	DRAG LEVER WASHER
65	E73-9103	SIDE PLATE SCREW
66	E77-2001	DRAG LEVER
67	E68-4202	DRAG LEVER COLLAR
68	E75-9401	CLICK PAWL
69	M16-3301	CLICK PAWL SPRING
70	E72-8201	CLICK PAWL COLLAR
71	E77-3201	PRESET CAM(A)
72	E77-3301	BUSHING
73	E62-7793	BUSHING RETAINER
74	E77-3701	PRESET CAM(B)
75	E77-3601	O RING
76	E68-4801	CLICK LEAF SPRING
77	H48-4801	DRAG KNOB SPRING
78	E77-3801	PRESET DRAG KNOB
79	G43-9401	BALL BEARING(F)
80	E72-9301	HANDLE CAP(A)
81	E77-3901	HANDLE ASSEMBLY
82	E74-6101	HANDLE SCREW
83	H42-6101	HANDLE PLATE
84	350-8912	HANDLE PLATE SCREW
85	H42-6301	HANDLE LEVER PLATE
86	H42-6201	HANDLE LEVER PLATE SPRING
87	H42-6401	HANDLE LEVER
88	H56-2102	HANDLE CAP(B)
89	G04-0815	HANDLE CAP SCREW
90	E74-2003	CLAMP BOLT
91	J01-4404	ROD CLAMP
92	H60-0801	CLAMP NUT
93	E62-7794	BUSHING WASHER

SAGLD60-2SPD Special Parts

Key No	Part No	Description
1	E77-5601	FRAME
9	E67-9610	FRAME PLATE
15	E77-5901	SPOOL
17	E77-6001	MAIN SHAFT
34	E77-2802	RIGHT SIDE PLATE